How to use SRM2366:

| SRM	Assign value to →	Everyday use calibrant

- Run SRM as the standard in a calibration curve and treat your everyday use calibrant as an unknown.
- Write the new – SRM assigned – value on the everyday use calibrant tube
- Use this new – SRM assigned– NIST traceable value for your everyday quantifications
- When changing lots of everyday use calibrant, repeat the above procedure to assign a NIST traceable value to the new lot