



Executive Summary

Orolia is pleased to respond to NIST's RFI "Profile of Responsible Use of Positioning, Navigation and Timing Services" [85 FR 31743]. Orolia is a world leader in Resilient PNT Systems and Services. In this document, we share our expertise on how to detect, protect, and prevent disruption or manipulation of PNT signals and sources, upon which much of our national critical infrastructure depends.

Reliance upon GPS for PNT for the last two decades by civilian applications has been an overwhelming success, providing increasingly accurate and reliable PNT information everywhere for free. However, in recent years, malicious threats have emerged that exposed the Achilles heel of GPS: Its weak power and unencrypted signal format leaves it vulnerable to jamming and spoofing. The loss of PNT information to various sectors can result in rare but catastrophic events, crippling critical infrastructure necessary for our survival.

Fortunately, there are a multitude of alternative technologies available to augment GPS and provide accurate and reliable PNT information even under extremely adverse conditions. These include:

- Low Earth Orbit (LEO) PNT satellite signals – operating close to the Earth with signal strengths ~1000x stronger than GPS to overcome jamming and encrypted to prevent spoofing.
- Miniaturized, affordable atomic clocks to provide precise time – the foundation of every positioning system – internally, without connection to, or reliance on, outside sources which could corrupt the precision.
- Fiber optic network time distribution via secure, high accuracy protocols.

We also offer recommendations for procedures and processes to manage and avoid the risks of cyber-attacks, applying the best practices known today.

Introduction

The various critical infrastructures dependent upon PNT and the impacts on their services if they were to be interrupted or manipulated are best known by each individual sector and will not be addressed in our response. Rather, we will focus on our area of expertise – Resilient PNT – and describe the strategies, technologies, and procedures to avoid cybersecurity risks and ensure the continuity of any critical operation.

Counter-attack approaches may differ across the various critical infrastructure sectors, so we will describe where different approaches or technologies are applicable. Also, please note that in addition to the critical infrastructure sectors identified in the RFI (Electrical Power Grid, Communications Infrastructure and Mobile Devices, all Modes of Transportation, Precision Agriculture, Weather Forecasting, and Emergency Response), we have added one more important one: Data Centers. With the move to ubiquitous Cloud Computing, Data Centers have thousands of servers operating simultaneously on the same data globally. This requires precise time synchronization. Moreover, because much of the data is from mobile applications, positioning is crucial. So, the Data Centers at the heart of Cloud Computing – Google searches, e-commerce, email services, hosted applications, etc. – rely heavily on PNT. This is often lumped under Communications Infrastructure, but it has its unique issues. And a specific case of Data Centers is Financial Services. The Stock Exchanges, and High Frequency Trading applications in particular, need precise, sub-microsecond level time sync to operate.

Strategies to Manage the CyberSecurity Risks for PNT

The main strategy is not to rely on any single PNT source. GPS, as great as it is in providing the necessary PNT accuracy and coverage, has shown itself to be very vulnerable to jamming and spoofing. However, no other PNT source is foolproof. Each has its own strengths and weaknesses. Therefore, we believe the best strategy is to use multiple, diverse PNT sources together—ones that have different failure modes and characteristics so the vulnerabilities of one source are counteracted by the strengths of another. Algorithms exist that can intelligently select and combine various PNT sources into a composite solution.




Figure 1 – Various PNT Sources to Make Critical Infrastructure Resilient

In Figure 1 we identify the many PNT technology sources available, and in Table 1 we show the applicability of each source to the critical infrastructure sectors. As shown in the legend, a technology is either applicable or it is not. In addition, we identify whether the applicable technology is lacking in accuracy or coverage – it can be used, but improved accuracy or coverage is highly desirable. In other cases, a technology may not be applicable because, for example, it provides only position when timing is required, or because accuracy or coverage is insufficient to meet even minimal requirements. These classifications are very general, and there are always exceptions and special cases, but it is a starting point for where each is mainly used.



Table 1 – PNT Source Technologies Applicability to Critical Infrastructure Sectors

PNT Technologies	Auto-motive	Air Nav	Sea Nav	Rail	Ped-estrian	Telecom	Data Centers	Power Grid	Precision Ag	Public Safety
PNT RF Sources										
GPS	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
Other GNSS	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
LEO PNT	◇	◇/□	◇	◇	◇	◇	◇	◇	◇/□	◇
Dedicated Terrestrial Tx	□	□	○	◇/○	◇	◇/○	□	◇/○	□	◇/○
eLoran	□	◇/○	◇/○	◇/○	◇/○	◇/○	□	◇/○	□	◇/○
VOR/TAC/DME/ILS	X	◇	○	○	X	X	X	X	X	X
Signals of Opportunity										
Cellular	□	□	○	◇	◇	X	◇	◇	□	◇
WiFi	□/○	□/○	□/○	□/○	◇	□/○	□/○	□/○	□/○	□/○
Broadcast TV	□	□	○	□	◇	◇	□	◇	□	□
RFID	◇	X	X	◇	◇	X	X	X	◇	◇
Autonomous										
IMUs	◇	◇	◇	◇	◇	X	X	X	◇	◇
Atomic Clocks	X	◇	◇	◇	X	◇	◇	◇	◇	◇
Map Matching	◇	◇	◇/○	◇	◇	X	X	X	◇	◇
Networked										
Timing	X	X	X	X	X	◇	◇	◇	X	◇
Crowd Sourced/Collaborati	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
Vision										
Video and IR cameras	◇	◇	◇	◇	◇	X	X	X	◇	◇
Lidar	◇	◇	◇	◇	X	X	X	X	◇	◇
Radar	◇	◇	◇	◇	◇	X	X	X	◇	◇
Sonar	◇	◇/□	◇	◇	◇	X	X	X	◇	◇
Sensing										
Magnetic	◇/□	◇	◇	◇	◇	X	X	X	□	□/○
Celestial (Sextant) - night	◇/○	◇/○	◇/○	◇/○	○	X	X	X	◇/○	X
Sky Polarization- day	◇/□	◇/○	◇/○	◇/○	○	X	X	X	◇/○	X
Odometer/Pedometer	◇/□	X	X	◇/□	◇/□	X	X	X	◇/□	◇/□/○
Legend										
	◇	Applicable								
	□	Lacking in Accuracy								
	○	Lacking in Coverage								
	X	Not Applicable								

Technology Characteristics

- GNSS vs. GPS** – all GNSS systems (GLONASS, Galileo, Beidou, and GPS) are very similar in operation and have similar vulnerabilities and strengths, so using multi-constellations does not offer much diversity. They all share the same few frequency bands, so in general, if one system is jammed, they all are. However, using multiple constellations will yield independent verification of each system. It takes a more sophisticated spoofer to fake all constellations, but it can be done. The other advantage is it will catch an anomaly on an individual system. For example, the 13 microsecond glitch in GPS in January 2016, the error in the GLONASS system in April 2014, and the timing glitch in the summer of 2019 on Galileo, would all have been detected by systems using multi-GNSS receivers with appropriate cross-checking algorithms. On

the other hand, these other systems are quite new and their failure modes are still unknown. Furthermore, dependency on non-USA sources has national security issues too.

- **LEO PNT** – the broad applicability stated here is based not only on what is available today from [STL](#) transmitting from the 66 satellite Iridium constellation, but also includes the eventual performance expected when LEO PNT signals are available on thousands of satellites from other constellations such as OneWeb, Boeing, Space-X, etc. The accuracy limitations of STL today are due to two major factors: geometric dilution because not enough satellites are visible simultaneously, and the limited signal bandwidth. Neither of these two factors should be an issue for future systems.
- **Dedicated Terrestrial Transmitters** includes technology represented by [NextNav LLC](#), [Locata](#), [Phasor Lab](#) and others. These systems require installing a transmitting infrastructure, so are best used in specific environments such as urban centers, warehouses, or test ranges. Area of coverage depends on the allowed transmitter power.
- **eLoran**- does not exist operationally today in the USA, but it is applicable for a number of sectors if a large-scale build-out was implemented. Prior to the existence of GPS, LORAN was used for coastal and river marine navigation in the USA. A few dozen high power stations provided this coverage until the early 2000s. With today's Digital Signal Processing (DSP) technology, better accuracy and coverage is possible than before. With fewer than 100 stations, complete coverage of the USA populated areas should be possible; even less would be needed for timing only.
- **VOR/TAC/DME/ILS** – VHF Omnidirectional Range, Tactical Aircraft Control, Distance Measuring Equipment, and Instrument Landing Systems are all ground-based RF signals generated near and around airports for flight guidance. One can imagine these old systems could be adapted for other uses, but the signal structures were developed in the early to mid- 20th century for primitive wireless electronics, so much better approaches can be imagined. However, changes to these signal formats is encumbered by the massive avionics installed base to which compatibility must be maintained.

Signals of Opportunity are RF signals that were not designed for transmitting PNT information, but with little or no modification can be used to determine position or time.

- **Cellular** includes 4G/LTE and 5G networks. Positioning from cellular is done today, achieving better than 100m accuracy. 5G can provide higher accuracy than 4G/LTE, and further improvements can be considered so that position accuracy can approach GNSS, but as of today, it is less accurate. Not included here is how cellular provides the "Assisted GNSS" function – using the data network to transport navigation messages to the GNSS receivers faster and more reliably than receiving them directly from the satellite.
- **WiFi** is neither accurate nor provides sufficient practical coverage to be considered for anything but the Pedestrian use case, typically for indoor positioning.
- **Broadcast TV** assumes improvements would be made to synchronize existing transmissions, but further build-out would most likely not happen in the future because the bandwidth is far too valuable for 5G. Any specific build-out of this technology approach for PNT is related to the high-power case of Dedicated Terrestrial Transmitter signal described previously.
- **RFID** provides positional proximity indication and therefore is not useful in timing applications.



Autonomous sensors refer to self-contained devices that do not rely on outside connections or signals and therefore, in general, are resistant to jamming or spoofing.

- **IMUs** – an Inertial Measurement Unit (or when combined with a navigation processing unit and a precision timekeeping device is called an INS – Inertial Navigation System), measures forces on the object (vehicle) to determine position movement or attitude changes.
- **Atomic Clocks** are becoming smaller, lightweight, lower in power consumption and more affordable, enough to be practical in many applications today. They maintain precise time in the absence of GNSS for hours or even days, depending on the requirements. We call this interval of no access to GNSS the *Holdover Time*. Since timekeeping is a part of Inertial Navigation, a precise clock aids in navigation too.
- **Map Matching** is used in combination with other sensors. It provides registration to predefined lanes and can help improve accuracy. Examples are cars aligned to streets or an aircraft using terrain following from radar/lidar measurements aligned to internal digital maps to determine position and heading. As memory becomes cheaper and network connectivity becomes ubiquitous, detailed maps of the entire world can be available on-demand.

Networked schemes require connectivity to a network, either wired or wireless.

- Precise **Timing** can be transferred across a network and this is a very effective and secure method of synchronization. The protocols [Network Time Protocol \(NTP\)](#) and [Precision Time Protocol \(PTP\)](#) are in wide use today. The High Accuracy version of PTP, colloquially known as “White Rabbit” (WR) provides the best time distribution today with accuracies in the one nanosecond range. Network time distribution via fiber optic is the ideal, diverse complement to GNSS derived time sync. Together, they create accurate, reliable time sync much more resilient to attack. Moreover, recently the Internet Engineering Task Force (IETF) has adopted a [Network Time Security \(NTS\) standard](#) so these protocols can be secure. Additionally, a [Best Current Practices](#) document has been published that goes beyond just the simple compliance with the standards and informs system design engineers on how to best avoid attacks.
- **Crowd Sourced/Collaborative** methods work on the idea that if other nodes on a network to which you are connected know their positions, and you have some indication of your relative proximity to them, you can infer your own position. Indications of proximity include RF signal strength on a wireless network, or roundtrip packet delay on a wired network. Analogously for the time sync situation, multiple nodes on a network can consensually sync together without necessarily being connected to a master source like GPS. The more participants on the network, the better the probability to form a PNT solution and the smaller the error ellipse will be. Of course, Collaboration is not a PNT source itself, but when combined with diverse sources, it is a powerful estimation method.

Vision systems provide positional awareness much the same way as humans are aware of their locations – through visual cues to recognized landmarks. However, they do not help with time determination.

- **Camera** imaging combined with map matching provides both position and attitude determination.
- **Lidar** uses laser range finding to create a 3D point map of a surrounding area.



- **Radar** operates similarly to lidar but with much less angular resolution. It is less impacted by smoke/fog/rain/snow than optical methods and recent advances in semiconductors has made it very affordable.
- **Sonar** – not viable for high speed aircraft but it provides proximity detection for use with other methods.

Sensing is similar to Vision but with these unique characteristics:

- Sensing the Earth's **Magnetic** field is not a very accurate method for heading determination, but it can provide an approximate initial state for inertial navigation.
- **Celestial** navigation is an ancient form of navigation for mariners that has been automated with cameras and image recognition processing. However, stars are only visible on clear nights or at extremely high altitudes.
- **Sky polarization** sensing takes advantage of the phenomenon that the sun's light is polarized differently at various angles of incidence with the atmosphere. By knowing the date and time and a rough estimate of your latitude and longitude, you can obtain a precise estimate of north orientation. Combined with celestial navigation, this can provide compass direction in both day and night conditions, though it does not operate well under all sky conditions with cloud cover.

Infrastructure Sector Characteristics

- **Automotive** has two main requirements:
 1. Steering the vehicle for autonomous driving. This is a safety of life concern and GNSS is not reliable enough to be part of this function.
 2. Navigation – knowing where the car is and directing where it should go. This includes both the driver and driverless cases. Example: summoning a ride share car.
- **Air Navigation** has its own unique instrumentation systems (see VOR/TAC above) but two growing factors of concern are:
 1. ADS-B – the Automatic Dependent Surveillance-Broadcast system is dependent on accurate and reliable position indications derived from GPS. The integrity of these position reports will determine its safe operation. Moreover, the ADS-B signal itself can be spoofed, creating an additional risk.
 2. UAVs – the growing use of UAVs in more applications is driving the need to integrate them into the National Air Space. Accurate, reliable, and high integrity PNT is paramount for this to happen.
- **Sea Navigation** relies heavily on GNSS and in recent years has been subject to several spoofing and jamming attacks worldwide. GNSS position reports feed the Automatic Identification System (AIS), which communicates with other entities in the area, so bad reports can cause widespread confusion. The International Maritime Organization (IMO) is investigating new methods for resilient navigation.
- **Rail** needs PNT for Positive Train Control (PTC) to enhance safety and for efficient operations.
- In this chart we assume the **Pedestrian** does not have critical accuracy, reliability or integrity requirements and it is primarily for indoor use.


- **Telecom** has had two traditional uses for PNT:
 1. For the wireless cellular network as shown in Figure 2:

Cellular Network's Dependence on GNSS

GNSS receivers at each cellular basestation provides two services:

1. Time sync so all the cells transmit at the same time
2. Precise frequency so they all align

This ensures clean coverage in the overlapping regions of adjacent cells



Cellular and GNSS Relationships

current

1. Adjacent cell time and frequency sync
2. Assisted GNSS – nav msgs, time of day, and gross location received over cellular network (Mbps) instead of GNSS channel (50 bps) to shorten GNSS acquisition time
3. e911/eCall – cellular network provides ~100 M positioning required by law through combination GNSS and sector location/time of arrival

Figure 2: Cellular Wireless Networks and PNT

2. For legacy wireline synchronization of the Synchronous Data Hierarchy (SDH) network. This harkens back to when “T1” lines were the interconnection backbone for data networks. A Primary Reference Clock (PRC), which was a cesium-based atomic clock, provided the master timing for the entire network. Today, this has been mostly replaced by asynchronous packet-based connections (IP/Ethernet), though some legacy systems still exist. Wireline sync for SDH should not be a driver for future resiliency requirements.

Note that wireline sync for SDH (the application) should not be confused with Network Timing (the technology). The technology is still very viable, as previously described, it is just that the applications that use it have evolved. SDH is now obsolete and we do not need to maintain precise time for network transport.

- Data Centers** – The primary need for PNT here is to synchronize each processing element to a common time reference. This is necessary so each element knows which transaction happened first, which happened second, etc. Examples of Data Center operators are Google, AWS, Azure and Verizon. In most cases, all that is needed is relative sync, not absolute sync, to Coordinated Universal Time (UTC). However, when processing elements are separated across wide areas (different cities or countries), GPS sync is the simplest and most accurate way to achieve it. Sync accuracy determines the efficiency of multi-processing. The more uncertain two processing elements are of their relative time references, the more “guard” or “wait” time they must use to have transactions settle before continuing or risk the probability of an error.




Figure 3: Data Center Sync Application

A secondary need for PNT is for mobile data. As more and more transactions are executed from mobile users and, with the emergence of the Internet of Things (IoT), more physically moving objects are executing transactions. These data packets need to be accurately geo-timestamped for meaningful processing to occur. The quality of information extracted from “Big Data” mining is very dependent upon the veracity of the PNT tag.

With 5G comes more bandwidth, enabling more real-time applications to run in the Cloud. With this trend, latency and time performance monitoring will become more critical.

- The Power Grid** depends on precise time synchronization as shown in Figure 3. Keeping the 60 Hz AC power in phase across the grid is a challenge. The main device supporting this process is the PMU – Phase Measurement Unit. It monitors the sine wave against a reference time, usually GPS, and provides feedback to the systems controlling phase alignment. One degree of phase error in this 60 Hz sine wave is 46 microseconds, so accuracies of tens of microseconds in measurement are desired, though ~100s microsecond errors can be tolerated. The other class of devices requiring sync are the Digital Fault Recorder (DFR) and Sequence of Event Recorders (SER). To diagnose faults and determine causal relationships, one needs to have a common time reference to know what happened first, what happened next, etc. Just like many other sectors, the grid only needs relative time, not absolute UTC time, but when operating over wide distances, UTC or GPS time is the easiest way to access a common clock. Two trends are occurring in the power industry that will influence its evolving need for resilient PNT:
 - Distributed power generation – as we move from central power generation from coal, oil, gas and nuclear stations to renewables like wind and solar, the sources of power are more distributed, more dynamic, and less controllable than before. This adds

complexity to the phase controlling algorithms requiring more measurement points and stricter compliance to accuracy and reliability.

Power Grid Dependence on PNT




Figure 4: Power Grid Dependency on Precise Time

2. Smart Grid – a data network is being superimposed on the grid so that every device on the grid has network connectivity. For these devices to be managed and to interact with each other, they need PNT information to know where these millions of devices are and for them all to have a common time reference.
- **Precision Agriculture** requirements are quite similar to Automotive in that the position of vehicle (tractor, harvester, etc.) is being controlled; however, there some unique factors:
 - Primarily rural use where fixed infrastructure is not usually available.
 - Centimeter level accuracy for sensing operations – example are bud locations on fruit trees, moisture sensing probes, alignment with AUV cameras, crop yield measurements down to the individual plant, etc.
 - Early adopters to driverless vehicles because this sector does not have the complex problem of sharing the “road” with human drivers.
 - Attitude control and sensing (pitch, roll, yaw) is necessary.

Within this sector we also include Construction and Surveying, as they all have similar requirements.

- **Public Safety** covers three major facets:
 1. Precise location and navigation for police, fire, and medical teams in emergency situations. Examples: in a burning or earthquake-damaged building; underground in a subway tunnel; when physically disabled due to injury.



2. Frequency and Time synchronization of dedicated first responder radio networks (Simulcast).
3. Legally traceable time sync for 911 call centers so recordings and response times can be used as evidence in courts.

Techniques for Detecting Disruptions or Manipulation of PNT Sources

After a dependent infrastructure is set up with multiple, diverse PNT sources, the best and simplest method for detection is to look for disagreement among the sources. With diverse sources, each one will have different points of vulnerabilities and different failure modes, so failures or attacks will manifest themselves in each source differently. For example, consider a timing system with three distinct sources: GNSS receiver, atomic clock, and PTP WR fiber network time. Jamming or spoofing of the GNSS signal will cause disagreement with the atomic clock and PTP-derived time; failure of the atomic clock will be detected by disagreement with GNSS and PTP time; hacking of the network with a Denial of Service (DoS) or Packet Delay attack will be detected by the GNSS and atomic clock. There is no signal point failure.

Similarly, for a positioning example, consider a vehicle with GNSS receiver, an IMU, and STL receiver. Jamming of the GNSS receiver would normally force the tracking to be open loop, relying on the IMU only which would drift over time. However, with updates from the STL signals, which are 1000x stronger than GPS and more resistant to jamming, the error drift is limited to tens of meters indefinitely. Spoofing of the GNSS signal is detected by either disagreement with STL, which is an encrypted signal that cannot be spoofed, or by the IMU which is not sensing movement in the false direction. Failure of any one of these three sources is noted by the agreement of the other two. Majority wins.

Each individual PNT source has its own detection and prevention measures. For example, there are [many jamming and spoofing detection algorithms](#) which can be applied to GNSS receivers to alert and often forewarn the infrastructure system of a possible disruption. False alarming is an issue, so using a probability-based scoring system with programmable thresholds can be helpful to keep both the false alarm and the missed detection rates low.

A simple GNSS spoofing detection technique is to use two separate receivers and antennas, spaced apart by a known distance. For example, placing one receiver/antenna combination at the fore of a ship, the other aft, will always yield two different position indications under normal operating conditions based on their separation. If ever they indicate the same position, it is an indication of spoofing from an external source.

Detecting dropouts, discontinuities, or other anomalous behavior from a particular sensor is another method of alerting. In this universe, it is impossible for an object to “jump” across the time-space continuum; it must move smoothly from one point in space-time to another and not exist at more than one point at any single instance. Therefore, an indication of discontinuity – within the bounds of measurement noise and quantization effects – is a potential failure or false manipulation of the source. Discontinuity, measurement range checking, and sensor behavior monitoring can be powerful detection methods.

Techniques for the Recovery and Response – Making PNT Systems Resilient

Again, with multiple, diverse PNT sources feeding a composite PNT solution, detection of a compromise or fault on any one source allows it to be dropped. Recovery is quicker and more effective the earlier



the detection. Kalman Filtering, Particle Filtering, and Artificial Intelligence (AI) techniques provide for the intelligent combination of multiple PNT sources into a single solution based on probability models.

Taking preventative measures before an attack can sometimes be the best response. These include:

- **Vulnerability Testing** – PNT systems should be analyzed and tested before they become part of critical infrastructure. For example, the University of Texas at Austin has established a standard battery of spoofing tests for GNSS receivers ([TEXBAT](#)); GNSS [Vulnerability Test Systems](#) are available from various vendors; [Certification testing](#) of GNSS receivers is available and required by some standards organizations; DHS is establishing the [Resilient PNT Conformance Framework](#) to characterize all PNT sources and their behavior under cyber-attack.
- **Protecting** the individual PNT source – GNSS receivers can be protected from cyber-attacks using “smart antennas”. These range from expensive, multi-element Control Radiation Pattern Antennas (CRPA), which track the individual satellites with narrow beams as they move across the sky and block interference, to inexpensive horizon blocking anti-jam antennas or simple two-element null steering antennas which search and block out interference.
- **Monitoring and Logging** attack events –the threat landscape is dynamic and we must adapt with new strategies as they arise. Creating threat libraries as they occur and sharing these across the PNT community helps to counter them.

Other Considerations

In this section, we offer some innovative, “out-of-the-box” ideas for consideration by the US government to make PNT systems more resilient:

- Consider the cessation of the leap second. Though this requires the international treaty agreement to change, NIST, along with USNO and BIPM (France) are the recognized world leaders for timekeeping. If they took the initiative, everyone would follow. The unnecessary complexity of managing this is a security risk – every few years we risk a glitch event. For example, more systems based on atomic clocks could run autonomously from GNSS for months (and therefore be less vulnerable) if they did not have to connect with GNSS to obtain UTC time as often to react to possible leap second notices. At its inception, the GPS system acknowledged leap seconds as an unnecessary risk and it does not use them internally. Instead, GPS just publishes the leap second variation data so users can convert GPS time to UTC time. It is a manageable activity because most systems respond properly to leap second events, but every so often, some system handles it improperly. Why not avoid stressing the system by eliminating it entirely?
- Consider using SAASM GPS receivers at our most vulnerable, high-valued critical infrastructure points. For example, post a USMC detachment with SAASM equipment at the NYSE exchange to protect the precise timing, manage the crypto keys, etc. The federal government has the constitutional authority to regulate interstate commerce and this could be implemented in that context and without violating Posse Comitatus if coordinated with the states. Some examples: the governors of New York or New Jersey could request the federal government to provide this protection for the Financial Services sector if they were aware of its availability; the Commonwealth of Virginia could authorize it for its new Amazon Data Center; etc. Moreover, as the US military moves toward activation of M-code, the older P(Y) signal has less utility for



military use and any concern of exposure to compromise by the increased proliferation of crypto keys in the civilian sector will reduce over time. In the interim, Orolia has patented technology that can convert the authenticated SAASM signal to a local re-broadcast of the civilian signal, reducing the number of SAASM receivers necessary. In the long term, the P(Y) signal used on SAASM could become the secure, encrypted civilian source when the military has fully transitioned to M-code. In Europe, the Galileo program has taken this approach in providing the Public Regulated Service (PRS) as the secure civilian signal for critical infrastructure.

- Consider protection of GNSS spectrum via enforcement – jamming and spoofing detection equipment is available today which could be placed at airports and seaports to detect and locate bad actors so they can be engaged and disarmed. However, it has been difficult for us to find the government agency with the mandate for providing this surveillance and the authority to pursue the perpetrators. The FAA ensures the safety at airports via air traffic management, but GPS disruption monitoring and reporting is left to the pilots. DHS has the authority for port protection, but there is no program we can find for GNSS signal surveillance at the ports. The issue extends beyond just safety to maintaining efficient operations. Container handling at the ports depends on GNSS for locating each container for loading, unloading, and processing. Disruption of GNSS can and has created chaos. It is not uncommon for truckers to use illegal “privacy” GPS jammers, which, when they pull into the port, disrupt operations. Who within the government has the mandate to address this problem? The [USCG NAVCEN](#), the [FAA](#), and the USAF all have websites for manual reporting entries, but this is too slow and cumbersome to address any dynamic threats meaningfully.
- In addition to enforcement, setting up a network of monitoring stations can provide the intelligence needed to mitigate any GNSS jamming or spoofing. Imagine if every cell tower had inexpensive GNSS interference sensors and reported back to a central database any detected signal disruptions. Just as NOAA has a network of radars and publishes real-time severe weather alerts, a similar “GPS Weather” reporting system could provide real-time warnings and advisories. Infrastructure owners could react quickly to these reports, knowing where and when the trouble spots occur. A library of threats would also be built so GNSS receiver manufacturers can continually improve their designs to counter these threats. This is not a far-fetched concept. Cell towers already contain GNSS receivers for providing precise time and frequency sync. As new more resilient receivers and antennas are installed, the vulnerable components can remain, acting as sensors and reporting alerts on the network. In Europe, the [STRIKE3 program](#) has been monitoring and cataloging GNSS interference events for years, providing Eurocontrol with the signal intelligence needed to maintain safe air navigation. A similar program in North America would be very valuable.
- Consider NIST endorsing encrypted Time as a Service (TaaS) – though no one method of providing PNT is impervious to attack, providing time sync over public fiber optic network is a diverse and secure time distribution alternative to GNSS. NIST has been offering its ~1 millisecond [Internet Time Service](#) for years. Additionally, NIST offers a [Special Calibration Service](#), which will provide a fiber optic connection to NIST, calibrated initially at installation. However, to maintain assurance, this requires repeated calibration campaigns, traveling to the client’s site with portable measurement equipment. Instead, we suggest that NIST provide some certification or endorsement of any commercial entities providing TaaS. There are two



main alternatives here: a public or private offering. A completely public offering would have the US government offering TaaS to the public for a fee; a completely private offering would have NIST endorsing the standards to be met by any company offering TaaS. A more realistic approach could be a public/private partnership in which private firms provide the equipment and network operations, and the government provides the national asset facilities along with the certification processes to ensure quality of service. It may not be practical for private companies, for example, to deploy multiple H-maser atomic clocks around the country and network them together, but co-location of network time equipment at NIST facilities in Boulder, CO or Gaithersburg MD, or at the US Naval Observatory in Washington DC could enable a reliable TaaS. Critical infrastructure owners and operators would be assured that their time is sourced from the national time standard and transported over a secure, certified network connections.