

Analytics and Metrology for Locally Strained Silicon in CMOS devices

Michael Hecker, Liang Zhu, Carsten Georgi, Inka Zienert, Jochen Rinderknecht, Holm Geisler, and Ehrenfried Zschech
AMD Saxony LLC & Co. KG, Dresden



2007 Int. Conference on Frontiers of
Characterization and Metrology for
Nanoelectronics




Outline of talk

- I. Strain in Si structures
- II. Strain metrology
- III. Focus: NanoRaman



I. Strain in Silicon Structures



propagation delay

$$t_d = C U_d / I_d$$



carrier mobility

gate oxide thickness

gate length



$$I_{d,sat} \sim \mu / (L \cdot T_{ox})$$

historical approach

- shrink gate length
- shrink gate oxide thickness


alternative, today's approaches

- higher carrier mobility (μ) in transistor channel.




local strain – dedicated strain at transistor channel

NMOS



PMOS



electrons -> tensile

$$\sigma_{xx} = +1 \text{ GPa} \rightarrow \mu \uparrow 30\%$$

holes -> compressive


$$\sigma_{xx} = -1 \text{ GPa} \rightarrow \mu \uparrow 70\%$$

calc. numbers: piezoresistance effect (Krivokapic et al., Sol. State Techn. 2004)

calculated stress in transistor channel: impact of embedded SiGe



model:
continuous distribution
of virtual interface dislocations



-> general stress state in PMOS channel:


$$\begin{aligned}\sigma_{xx} &<< 0 \rightarrow \text{high } \mu\text{-sensitivity} \\ \sigma_{yy} &>> 0 \rightarrow \text{low } \mu\text{-sensitivity} \\ \sigma_{zz} &> 0 \rightarrow \text{high } \mu\text{-sensitivity}\end{aligned}$$

$$\Delta\mu_{\langle 110 \rangle} / \mu \approx (-0.72 \sigma_{xx} + 0.01 \sigma_{yy} + 0.66 \sigma_{zz}) / \text{GPa}$$

hole mobility enhancement in p-Si


[Smith, Phys. Rev 94 (1954); Thompson, IEEE 51 (2004)]

impact of cavity geometry on SiGe stress




Hecker, Geisler: Mat. Sci. Pol. 25, 7 (2007)

II. Strain metrology



dislocations in NMOS
of 90 nm devices
(source: D. James,
Chipworks, 2005)



wafer curvature : stress = force/area (Stoney eqn.)


X-ray : lattice parameter (Bragg eqn.)

TEM : lattice parameter (CBED, NBD, HRTEM)


Photoluminescence : strain -> band gap change

Raman : strain via lattice vibrations




strain measurement by TEM



CBED




NBD




Engelmann, Heinemann, Zschech: IMC16, 990 (2006)

Raman strain measurement

Raman-principle





confocal microscope






- nondestructive
- fast
- spatial resolution $< 1\mu\text{m}$

Raman measurement




film stack for Raman calibration: sSOI/SiGe




-> calibration for defect-free films

X-ray strain measurement

004 map



224 map



004: strain normal to surface

224: in-plane strain

Δl -> sSOI strain
 -> Raman strain parameters
 $\sigma = -235 \text{ MPa cm } \Delta\omega$

“quick” measurements -> I-scan, h-scan
 detailed information -> reciprocal space map

III. Nano-optics and field enhancement

The Lycurgus Cup





reflected / transmitted light
(TEM: 50 nm Au particles)

particle-related field enhancement due to:
electromagnetic effect




surface plasmons
-> antenna effect
-> high efficiency of plasmon excitation in Ag, Au

chemical effect

increased polarizability due to charge transfer metal -> sample



Surface enhanced Raman scattering (SERS) close to Ag particles




1: layer: +91% substrat -10%
 2: layer: +153% substrat +23%
 3: layer: +134% substrat +65%

L. Zhu et al.: Mat. Sci. Pol. 25, 19 (2007)


From surface enhanced to **Tip Enhanced** **Raman Scattering (TERS)**

(1) aperture based



long-working-distance objective





(2) apertureless (TERS)



tip etching apertures



TERS tips




mounted on
tuning fork

Y. Ritz et al.: Pract. Metallogr. 38, 403 (2006)


samples

strained silicon on insulator (sSOI)




sample patterning for studies of spatial Raman resolution by FIB technique





SiGe-layer fully strained on Si-bulk



Raman film peak Si-Si: shifted to smaller wave numbers







(1) measurements with near-field-aperture



~ 300 nm spatial resolution with aperture, compared to ~ 800 nm

(2) measurements with TERS-tips





selective enhancement $\sim 70\%$

Resolution of sSOI line structures below diffraction limit by TERS



Raman peak intensity



- **improved contrast**
- **more features resolved in sSi film peak intensity**
- **resolution ~ 250 nm**


scan parameters:

488 nm laser, 10 mW, 3 s, step size 40 nm

L. Zhu et al.: Journ. Appl. Phys., submitted (2007)

strain distribution in sSOI line structures

Raman peak position



➤ strain profile in wider lines: relaxation at line edges visible (2000 .. 600 nm)

➤ tendency of higher relaxation for narrower lines visible



evaluation for assumption of stress conservation along line direction and partial relaxation perpendicular to lines:

$$\frac{\sigma_{x'x'}}{\sigma_0} = -0.455 \cdot \left(\omega_{sSi} - 520 \text{ cm}^{-1} \right) - 1$$


strain investigation in between SiGe cavities (test structures)



100 nm Si lines in between 300 nm SiGe cavities, scanned with FIB modified TERS tip




Raman measurement:
~ 50% signal enhancement



strain investigation in between SiGe cavities (test structures)


Raman peak intensity




scan parameters: 488 nm laser, 10 mW, 3 s, step size 16 nm

strain in between SiGe cavities – comparison with calculation


Raman data



model for strain calculation




strain in channel



calculated resulting peakshift

$$\Delta\omega_{Si} = (\sigma_{xx} + \sigma_{zz}) \cdot C_1 + \sigma_{yy} \cdot C_2$$

Si peak shift due to strained Si: approx. 1cm⁻¹



Summary for strain metrology



- X-ray: sample throughput, spatial resolution
- Raman: weak signals (near field), not all materials
- sample preparation for sub-100nm measurements critical



- strain increases transistor speed -> high motivation to measure
- spatial resolution of techniques continuously scales down
- near-field Raman has potential for local strain measurements

Trademark Attribution



AMD, the AMD Arrow Logo, and combinations thereof, are trademarks of Advanced Micro Devices, Inc. Other product names used in this presentation are for identification purposes only and may be trademarks of their respective companies.

© 2007 Advanced Micro Devices, Inc. All Rights Reserved.