

## **APPENDIX J. HYDROGEN CYANIDE ANALYSIS**

---

### **J.1 HYDROGEN CYANIDE REPORT**

This work was contracted with the US Army Aberdeen Test Center and performed by Dr. Steven H. Hoke of the Chromatography Analysis Division.

**TEST #: 1 Sprinkler** September 5, 2003

**TEST #: 2 No Sprinkler** September 10, 2003

**ORGANIZATION:** NATIONAL INSTITUTE OF STANDARDS AND TECHNOLOGY,  
GAITHERSBURG, MD

**TEST FIXTURE:** Rhode Island Test

**SETUP:** Two sampling positions were used to conduct real-time hydrogen cyanide analysis on two different test days at NIST. The two sampling positions were designated position 1 (West – NIST Location D) and position 2 (East- NIST Location C), and were 3.66 m and 1.83 m west of the stage, respectively. Each sample position was located 1.5 m off the floor and 2.74 m from the south wall of the compartment (Figure J-1).




Figure J-1. Sampling positions inside Rhode Island test fixture.

## DRAFT

The Sampling equipment was located on a table just outside the south wall of the compartment. Air samples were taken through a ¼-in. o.d. 304 stainless steel tubing. An additional 3 ft. of stainless steel tubing was placed on the outside to provide for cooling of the hot sample gases. A stainless steel 4-port sampling manifold using Swagelok tees was attached to the end of each sample line. Red silicone tubing was used to attach samplers to the manifold (Figure J-2).




Figure J-2. Sampling set up at Position 1 for test 1.

At each sampling position two impinger samples were taken, one with a filter and one without. Each of these impingers used 0.1 M KOH as trapping solution. For the first test two mini gas real-time cyanide analyzers were used at position 1 and a suitcase-size version of the analyzer was used at position 2. For test 2 a mini gas analyzer was used at each position. Airflow rates were measured and recorded before each test. Voltage signals from the analyzers were recorded on data loggers and also sent to the main control computer.

With the high gas temperatures anticipated a 3-ft. extension of stainless steel tubing was attached between the exterior wall and the sampling manifold. To determine the cooling effect this had on the sample gases, a T type thermocouple was attached to the stainless steel tubing just outside the wall and one just before the sampling manifold. A Fluke model 2635A Hydra Series II Data Bucket collected data from each of the

## DRAFT

two thermocouples. This data was only collected for the second test because higher temperatures were anticipated.

After the second test both of the 9-ft. stainless steel lines were removed from the test fixture and rinsed in a vertical position with 10 mL of 0.1 M KOH.

Upon returning to the laboratory the filters were weighed and then placed in a screw cap-polypropylene test tube with 10 mL of 0.1 M KOH.

After each test the contents of the impingers were transferred to a test tube and labeled.

Impinger samples were analyzed according to NIOSH Method 7904.

The real-time mini gas analyzers as described elsewhere (Paper submitted to J. Process Anal. Chem. for publication) were modified to use an off-the-shelf cyanide combination electrode and 0.1 M KOH as the trapping solution. Calibration standards were prepared in 0.1 M KOH using KCN at levels of 2, 5, 10, and 30-ppm cyanide. This corresponds to an upper and lower calibration limit in air of 153 and 10 ppm HCN, respectively. The gas analyzer showed linearity up to 1284 ppm HCN in air, so the high values obtained during the second test can be considered valid.

### RESULTS:

Figures J-3 to J-5 show real-time results from the three HCN gas analyzers used for test 1 conducted on 5 Sept 03. The automatic sprinkler system activated at about 25 sec.; therefore, there was very little HCN produced.




Figure J-3. Hydrogen cyanide response from mini gas analyzer located at position 1.

# DRAFT

Test Number NIST 1  
September 5, 2003  
Analyzer Number Position 1B, MG2




Figure J-4. Hydrogen cyanide response from mini gas analyzer located at position 1.

Test Number NIST 1  
September 5, 2003  
Analyzer Number Position 2B




Figure J-5. Hydrogen cyanide response from large gas analyzer located at position 2.

## DRAFT

Figures J-6 and J-7 show real-time results from the two mini gas HCN analyzers used for test 2 conducted on 10 Sept 03. This fire burned much longer and as indicated by the response produced much higher values of HCN.




Figure J-6. Hydrogen cyanide response from mini gas 1 located at position 1




Figure J-7. Hydrogen cyanide response from mini gas 2 located at position 2.

## DRAFT

Impinger and filter samples were analyzed according to NIOSH method 7904.

<b>Table J-1. Impinger data for Rhode Island Tests.</b> <b>(All values reported in ppm HCN for the indicated run time. )</b>					
Position	Test Date	Impinger ppm HCN	Impinger (Filter) ppm HCN	Filter ppm HCN	Run Time
1 (West) (NIST Sample Location D)	5 Sept 03	5.0	4.7	BDL	8 min.
2 (East) (NIST Sample Location D)	5 Sept 03	5.1	5.0	BDL	8 min.
1 (West) (NIST Sample Location D)	10 Sept 03	213	153	BDL	1.67 min.
2 (East) (NIST Sample Location D)	10 Sept 03	248	176	BDL	1.67 min.
BDL= Below Detection Limit of 2.5 ppm.					

For example at Position 1 on 5 Sept 03 the impinger measured an 8-min. TWA of 5 ppm HCN. At Position 1 on 10 Sept 03, a TWA of 213 ppm HCN was measured over a time of 1.67 min.

The impinger values may be low compared to the gas analyzer values because the impinger bubbler may not quantitatively collect aerosol forms of HCN.


The impingers behind the filters were expected to be lower than those of the impingers with no filters because any HCN collected on the filters, as aerosols would not be part of the impinger measurement. Because of the large amount of particulate matter on the filter, it was decided to estimate the total weight on the filter prior to cyanide analysis. However, any aerosol forms of HCN on the filters from test 2 were lost because of the time required to obtain filter weights.

The filters were photographed after the second test because they appeared to have a large amount of particulate matter on them (photographs were not available to include in this report). For this reason it was

## DRAFT

decided to weigh the filters in an attempt to estimate exposure to total particulate matter. Since the filters were not pre-weighed, six new filters were weighed from the same pack to establish a tare weight. The weight of the filter from position 1 was significantly different from the mean so that <5% of the time we would be wrong in making that assumption. The difference between the mean filter weight and that of position 1 was 24.540 mg. This calculates to an exposure level of 12,649 mg/m<sup>3</sup>. This is considerably higher than the OSHA PEL TWA of 15 mg/m<sup>3</sup> (see attachment J-1). The weight of the filter from position 2 was not significantly different from the mean.

The data from the two thermocouples was recorded at 10-sec. intervals. The figure below shows that the 3-ft. extension successfully cooled the sample gases prior to entering any of the sampling devices.



After the first test one of the 9-ft. line was rinsed with 10 mL of 0.1 M KOH. After test 2 both of the 9-ft. stainless steel sample lines were rinsed. For the second test both of the rinses has a yellow tinge; however, line 2 rinse was much darker. Analysis of all three samples for anions by ion chromatography showed a small amount of chloride and a very large amount of sulfate ion. The amount of HCN measured in the rinse samples represented only a few percent of the total HCN measured.

Two foam samples, one unburned and one partially burned, from the test on 5 Sept 03, were submitted to the FTIR lab at the Aberdeen Test Center for analysis. The pyrolysis and combustion analysis both showed the presence of hydrogen cyanide and organo isocyanates, which could include methyl isocyanate. According to NIOSH and OSHA methyl isocyanate is much more of an exposure hazard than hydrogen cyanide (Appendix FF-2 and FF-3).

## ***DRAFT***

The attached report summarizes the FTIR work. This FTIR technique could be a valuable tool for predicting the types of compounds to sample for prior to conducting the actual test burn. In this way the proper sampling devices could be obtained and the calibration ranges could be adjusted to match anticipated levels of combustion products produced in a fire.

Steven H. Hoke Ph.D., CIH

USACHPPM

Bldg. 363

APG, MD 21005-5059

Phone 410-278-2269

Fax 410-278-9622

[Steven.hoke@apg.amedd.army.mil](mailto:Steven.hoke@apg.amedd.army.mil)





## **J.2 NIOSH POCKET GUIDE TO CHEMICAL HAZARDS**

### **J.2.1 Particulates not otherwise regulated**

#### **CAS RTECS**

##### **Synonyms & Trade Names**

"Inert" dusts, Nuisance dusts, PNOR [Note: Includes all inert or nuisance dusts, whether mineral, inorganic, not listed specifically in 1910.1000.]

**DOD ID &**

##### **GuideExposure**

**Limits** NIOSH REL: [See Appendix D](#)

OSHA PEL: TWA 15 mg/m<sup>3</sup> (total) TWA 5 mg/m<sup>3</sup> (resp)

**IDLH** N.D. See: [IDLH INDEX](#)

**Conversion**

##### **Physical Description**

Dusts from solid substances without specific occupational exposure standards.

Properties vary depending upon the specific solid.

##### **Incompatibilities & Reactivities**

Varies

##### **Measurement Methods**

NIOSH [0500](#), [0600](#)

See: [NMAM](#) or [OSHA Methods](#)

##### **Personal Protection & Sanitation**

Skin: No recommendation

Eyes: No recommendation

Wash skin: No recommendation

Remove: No recommendation

Change: No recommendation **First Aid** ([See procedures](#))

Eye: Irrigate immediately

Breathing: Fresh air

[Important additional information about respirator selection](#)

**Respirator Recommendations** To be added later

**Exposure Routes** inhalation, skin and/or eye contact

**Symptoms** Irritation eyes, skin, throat, upper respiratory system

**Target Organs** Eyes, skin, respiratory system

See also: [INTRODUCTION](#)

## **J.2.2 Methyl isocyanate**

CAS 624-83-9

**CH<sub>3</sub>NCO** RTECS [NQ9450000](#)

### **Synonyms & Trade Names**

Methyl ester of isocyanic acid, MIC **DOT ID & Guide** 2480 [155](#)

**Exposure Limits** NIOSH REL: TWA 0.02 ppm (0.05 mg/m<sup>3</sup>) [skin]

OSHA PEL: TWA 0.02 ppm (0.05 mg/m<sup>3</sup>) [skin]

**IDLH** 3 ppm See: [624839](#) **Conversion** 1 ppm = 2.34 mg/m<sup>3</sup>

**Physical Description:** Colorless liquid with a sharp, pungent odor.

MW: 57.1 BP: 102 - 104°F FRZ: -49°F Sol (59°F): 10% VP: 348 mmHg IP: 10.67 eV

Sp.Gr: 0.96 FL.P: 19°F UEL: 26% LEL: 5.3%

Class IB Flammable Liquid: FL.P. below 73°F and BP at or above 100°F.

### **Incompatibilities & Reactivities**

Water, oxidizers, acids, alkalis, amines, iron, tin, copper [Note: Usually contains inhibitors to prevent polymerization.]

### **Measurement Methods**

OSHA [54](#)

See: [NMAM](#) or [OSHA Methods](#)

### **Personal Protection & Sanitation**

Skin: Prevent skin contact

Eyes: Prevent eye contact

Wash skin: When contaminated

Remove: When wet (flammable)

Change: No recommendation

Provide: Eyewash, Quick drench **First Aid** ([See procedures](#))

Eye: Irrigate immediately

Skin: Water flush immediately

Breathing: Respiratory support

Swallow: Medical attention immediately

[Important additional information about respirator selection](#)

**Respirator Recommendations** NIOSH/OSHA

**Up to 0.2 ppm:** (APF = 10) Any supplied-air respirator\*

**Up to 0.5 ppm:** (APF = 25) Any supplied-air respirator operated in a continuous-flow mode\*

**Up to 1 ppm:** (APF = 50) Any self-contained breathing apparatus with a full facepiece/(APF = 50) Any supplied-air respirator with a full facepiece

**Up to 3 ppm:** (APF = 2000) Any supplied-air respirator that has a full facepiece and is operated in a pressure-demand or other positive-pressure mode

**Emergency or planned entry into unknown concentrations or IDLH conditions:** (APF = 10,000) Any self-contained breathing apparatus that has a full facepiece and is operated in a pressure-demand or other positive-pressure mode/(APF = 10,000) Any supplied-air respirator that has a full facepiece and is operated in a pressure-demand or other positive-pressure mode in combination with an auxiliary self-contained positive-pressure breathing apparatus

**Escape:** (APF = 50) Any air-purifying, full-facepiece respirator (gas mask) with a chin-style, front- or back-mounted organic vapor canister/Any appropriate escape-type, self-contained breathing apparatus

**Exposure Routes** inhalation, skin absorption, ingestion, skin and/or eye contact

**Symptoms** Irritation eyes, skin, nose, throat; respiratory sensitization, cough, pulmonary secretions, chest pain, dyspnea (breathing difficulty); asthma; eye, skin damage; in animals: pulmonary edema

**Target Organs** Eyes, skin, respiratory system See also: [INTRODUCTION](#) See ICSC CARD: [0004](#) See MEDICAL TESTS: [0143](#)

## **J.2.3 Hydrogen cyanide**

### **CAS 74-90-8**

**HCN** RTECS [MW6825000](#)

#### **Synonyms & Trade Names**

Formonitrile, Hydrocyanic acid, Prussic acid

1051 [117](#) (>20% solution)

1051 [117](#) (anhydrous)

1613 [154](#) (<=20% solution)

#### **DOT ID & Guide**

**Exposure Limits** NIOSH REL: ST 4.7 ppm (5 mg/m<sup>3</sup>) [skin]

OSHA PEL†: TWA 10 ppm (11 mg/m<sup>3</sup>) [skin]

**IDLH** 50 ppm See: [74908](#) **Conversion** 1 ppm = 1.10 mg/m<sup>3</sup>

#### **Physical Description**

Colorless or pale-blue liquid or gas (above 78°F) with a bitter, almond-like odor. [Note: Often used as a 96% solution in water.]

MW: 27.0 BP: 78°F (96%) FRZ: 7°F (96%)

Sol: Miscible VP: 630 mmHg

IP: 13.60 eV

Sp.Gr: 0.69 Fl.P: 0°F (96%) UEL: 40.0%

LEL: 5.6%

Class IA Flammable Liquid Flammable Gas

#### **Incompatibilities & Reactivities**

Amines, oxidizers, acids, sodium hydroxide, calcium hydroxide, sodium carbonate, caustics, ammonia [Note: Can polymerize at 122-140°F.]

#### **Measurement Methods**

NIOSH [6010](#)

See: [NMAM](#) or [OSHA Methods](#)

#### **Personal Protection & Sanitation**

Skin: Prevent skin contact

Eyes: Prevent eye contact

Wash skin: When contaminated

Remove: When wet (flammable)

Change: No recommendation

Provide: Eyewash, Quick drench **First Aid** ([See procedures](#))

Eye: Irrigate immediately

Skin: Water flush immediately

Breathing: Respiratory support

Swallow: Medical attention immediately

[Important additional information about respirator selection](#)

#### **Respirator Recommendations** NIOSH

**Up to 47 ppm:** (APF = 10) Any supplied-air respirator

**Up to 50 ppm:** (APF = 25) Any supplied-air respirator operated in a continuous-flow mode/(APF = 50) Any self-contained breathing apparatus with a full facepiece/(APF = 50) Any supplied-air respirator with a full facepiece

**Emergency or planned entry into unknown concentrations or IDLH conditions:** (APF = 10,000) Any self-contained breathing apparatus that has a full facepiece and is operated in a pressure-demand or other positive-pressure mode/(APF = 10,000) Any supplied-air respirator that has a full facepiece and is operated in a pressure-demand or other positive-pressure mode in combination with an auxiliary self-contained positive-pressure breathing apparatus

**Escape:** (APF = 50) Any air-purifying, full-facepiece respirator (gas mask) with a chin-style, front- or back-mounted canister providing protection against the compound of concern/Any appropriate escape-type, self-contained breathing apparatus

**Exposure Routes** inhalation, skin absorption, ingestion, skin and/or eye contact

**Symptoms** Asphyxia; lassitude (weakness, exhaustion), headache, confusion; nausea, vomiting; increased rate and depth of respiration or respiration slow and gasping; thyroid, blood changes

**Target Organs** central nervous system, cardiovascular system, thyroid, blood

See also: [INTRODUCTION](#) See ICSC CARD: [0492](#) See MEDICAL TESTS: [0117](#)