

# Development of NFIQ 2.0

elham.tabassi@nist.gov

[http://www.nist.gov/itl/iad/ig/development\\_nfiq\\_2.cfm](http://www.nist.gov/itl/iad/ig/development_nfiq_2.cfm)

April 1, 2014

International Biometric Performance 2014

# Outline

- » What is quality?
- » History + Background
- » Sponsors + Team Members
- » Architecture
- » Features
- » Machine Learning
- » NFIQ 2.0 prototype
- » NFIQ 2.0 Lite (Mobile)
- » Actionable quality
- » Relation to ISO/IEC 29794-4
- » Discussion

# Quality assessment for error suppression

Quality problem: “The Last 1%”

Or maybe “The Last 0.1% or 10%”

» Fraction of samples that should not be sent to the matcher

- Core algorithmic capability of current matchers are reaching their asymptote. Performance improvements should be and could be achieved by improving data quality and integrity.
- Quality assessment should be done based on only one instance most of the times (representation).
- Providing constructive feedback only possible if cause of poor quality is known

character



behavior



environment



Imaging/system



# 2004 - present

2004

- Release of NFIQ 1.0
- Novel definition of biometric quality
  - performance related
  - accepted by the community
- Interoperability
  - uniform interpretation
  - tuned to a class of matcher
- Open source
- Extensively examined
  - by NIST and others
  - tools for quality summarization, slap, ...

2010 workshop

- Workshop on March 6, 2010 (IBPC 2010)
- **NFIQ 2.0 wish-list as of March 2010**
- Several options for NFIQ 2.0 were discussed
  - [http://biometrics.nist.gov/cs\\_links/ibpc2010/options\\_for\\_NFIQ2.0.pdf](http://biometrics.nist.gov/cs_links/ibpc2010/options_for_NFIQ2.0.pdf)
- The community overwhelmingly recommended a new, open source, generalized version of NFIQ to be developed in consultation and collaboration with users and industry.
- Same technical approach, but better, bigger, faster, etc.

2012 workshop

- Workshop on March 5, 2012 (IBPC 2012)

~~NFIQ 2.0 wish-list as of March 2010~~  
**Components as of March 2012**

- Community asked for:
  - providerID
  - Actionable flags
  - Versioning
  - Latent?

2013 Workshops

- Two Workshops
  - April 26, Sep 17 (BCC)
  - Presented prototype NFIQ2.0 for review and comment by the community
- Workshop on Sep 16 at Biometric Consortium



# NFIQ 2.0 Community

## Team Members

- » NIST (US)
- » BSI (Germany)
- » BKA (Germany)
- » Fraunhofer IGD
- » MITRE (US)
- » Hochschule Darmstadt / CASED
- » Secunet Security Networks AG
- » NFIQ 2.0 Participants
- » *...and the whole biometrics community*

## Sponsors



Homeland  
Security

Science and Technology



Federal Office  
for Information Security



Bundeskriminalamt

# Team Members

## US

- » Elham Tabassi (NIST)
- » Greg Fiumara (NIST)
- » Patricia Flanagan (NIST)
- » Carol Nowacki, Carol (MITRE)
- » Adam Day (MITRE)
- » Marc Colosimo (MITRE)
- » Martin Olsen (HDA, NIST)

## DE

- » Christoph Busch (HAD)
- » Oliver Bausinger (BSI)
- » Johannes Merkle (SEC)
- » Michael Schwaiger (SEC)
- » Christopher Schiel (BKA)
- » Timo Ruhland (BKA)
- » Alexander Nouak (IGD)
- » Olaf Henniger (IGD)
- » Martin Olsen (HDA, NIST)

# Challenges in development a fingerprint quality assessment algorithm

## Technical

- » Agnostic to comparison algorithm
  - Capability to predict performance of different comparison algorithms
- » Sufficient resolution
  - How many levels are too many?
- » Pairwise quality
  - $Q_1 = F(\text{image}_1)$  ;  $Q_2 = F(\text{image}_2)$ ;
  - $Q_{12} = G(F(\text{image}_1), F(\text{image}_2))$
- » Calibration
  - What FNMR is expected for each quality level/score?
- » Quality of quality
  - Performance measures



## Way forward

- » Get a good representation of the current (state-of-the-art) comparison algorithm for training
  - Include as many as possible
  - Requires building community
- » We really don't know.
- » Robust method for labeling training data + ultimately visual inspection
- » Devise + revise metrics and visualization techniques

# Challenges in development a fingerprint quality assessment algorithm

## Technical, etc.

- » Data + Data sharing issues
  - training (particularly low quality)
  - testing (Images with specific defects)
- » Agnostic to application scenario
  - 'sufficient quality' is different for enrolment vs. verification
  - Ditto 1:1 and 1:N.
- » Meet unknown System requirements
  - Timing, hardware, etc.
- » Robust
  - Zero failure to compute rate




## Way forward


- » Data cannot leave a site, but an open source algorithm can be ran on the data and Results can then be shared
- » Go for the best recommended by the community
- » Develop technical guidance and best practice
  - In collaboration with end users of the particular application
- » Good coding practice




# NFIQ 2.0 Framework



# NFIQ 2.0 comparison score provider





## NFIQ 2.0 FEATURES

NFIQ 1.0 features

Recommended Features in ISO/IEC 29794-4:2009 + our modifications

Surveyed literature + our modifications

Open source FingerJetFx minutiae extractor

# NFIQ 2.0 features

## Image/signal processing

- » Local clarity score
- » Ridge valley uniformity
- » Orientation certainty level
- » Orientation flow
- » Contrast
- » Radial power spectrum
  - Only in ROI
- » Gabor filters (several variants)

## Minutiae based

- » FingerJetFx
  - Open source implementation from digitalPersona
  - [Digitalpersona.com/fingerjetfx](https://digitalpersona.com/fingerjetfx)
- » Count of minutia in region of interest
  - Various selection of ROI
- » Count of 'good' quality minutia

Standardized features allow for plug and play of feature computation implementations that are semantically conformant to the standard (i.e., ISO/IEC 29794-4 and ISO/IEC 19794-4).

Different implementations are distinguished via providerID.

# ~180 features ...




Feature ID in Framework	Comments		
NFIQ1_Feature_1	Original NFIQ1 Feature 1	FJFXPos_OCL_MinutiaeQuality_0	Percentage of minutiae quality values (based on OCL value around each minutiae location) between 0 and 20
NFIQ1_Feature_2	Original NFIQ1 Feature 2	FJFXPos_OCL_MinutiaeQuality_20	Percentage of minutiae quality values (based on OCL value around each minutiae location) between 20 and 40
NFIQ1_Feature_3	Original NFIQ1 Feature 3	FJFXPos_OCL_MinutiaeQuality_40	Percentage of minutiae quality values (based on OCL value around each minutiae location) between 40 and 60
NFIQ1_Feature_4	Original NFIQ1 Feature 4	FJFXPos_OCL_MinutiaeQuality_60	Percentage of minutiae quality values (based on OCL value around each minutiae location) between 60 and 80
NFIQ1_Feature_5	Original NFIQ1 Feature 5	FJFXPos_OCL_MinutiaeQuality_80	Percentage of minutiae quality values (based on OCL value around each minutiae location) between 80 and 100
NFIQ1_Feature_6	Original NFIQ1 Feature 6	FJFXPos_OCL_4Blocks_AverageMinQuality	Average of minutiae quality that was computed based on the mean of all OCL values around each minutiae location (4 blocks around
NFIQ1_Feature_7	Original NFIQ1 Feature 7	FJFXPos_Coherence_AvgMinQuality	Average of minutiae quality that was computed based on the coherence value of the orientation map field of the block in which the mi
NFIQ1_Feature_8	Original NFIQ1 Feature 8	FJFXPos_Coherence_InhQual_AvgMinQual	Average of minutiae quality that was computed based on the inhomogeneity quality value of the enhanced contrast map
NFIQ1_Feature_9	Original NFIQ1 Feature 9	FJFXPos_MinutiaeFusion_1	Average of fused minutiae quality that was computed based on OCL, Mu, coherence values and enhanced contrast map values
NFIQ1_Feature_10	Original NFIQ1 Feature 10	FJFXPos_AvgMinReliability_QMEnh	Average of minutiae quality that was computed on the reliability value retrieved from the enhanced quality map
NFIQ1_Feature_11	Original NFIQ1 Feature 11	FJFXPos_AvgMinReliability_QMAdv	Average of minutiae quality that was computed on the reliability value retrieved from the advanced quality map
NFIQ1_Time_All	Speed computation of NFIQ1 features in ms	FJFXPos_MinutiaeFusion_2	Average of fused minutiae quality that was computed based on OCL, Mu, coherence values, enhanced quality map zones and enhan
FingerJetFX_MinutiaeCount	Number of detected minutiae (no limitation as in original FJFX source code)	FJFXPos_QualityMapEnh_AvgMinQual	Average of minutiae quality that was computed based on the quality zones determined by the enhanced quality map
FingerJetFX_MinutiaeQuality_0	Percentage of minutiae that have minutiae quality of 0 (= not calculated)	FJFXPos_LCS_AverageMinutiaeQuality	Average of minutiae quality that was computed based on block-wise LCS
FingerJetFX_MinutiaeQuality_1	Percentage of minutiae that have minutiae quality between 1 and 10	FJFXPos_RVU_AverageMinutiaeQuality	Average of minutiae quality that was computed based on block-wise RVU
FingerJetFX_MinutiaeQuality_2	Percentage of minutiae that have minutiae quality between 11 and 20	FJFXPos_LowFlow_AverageMinutiaeQuality	Average of minutiae quality that was computed based on block-wise values returned by the low flow map
FingerJetFX_MinutiaeQuality_3	Percentage of minutiae that have minutiae quality between 21 and 30	FJFXPos_Time_All	Speed computation of minutiae quality computation values
FingerJetFX_MinutiaeQuality_4	Percentage of minutiae that have minutiae quality between 31 and 40	OCL	Orientation Certainty Level (OCL) of whole image
FingerJetFX_MinutiaeQuality_5	Percentage of minutiae that have minutiae quality between 41 and 50	OCL_Time	Speed computation of OCL computation
FingerJetFX_MinutiaeQuality_6	Percentage of minutiae that have minutiae quality between 51 and 60	QualityMap_HighContrastBlocks	Number of blocks that have high contrast according to NFIQ1 low contrast map (re-implemented using OpenCV)
FingerJetFX_MinutiaeQuality_7	Percentage of minutiae that have minutiae quality between 61 and 70	QualityMap_Time	Speed computation of quality map computation (low contrast map, enhanced orientation map, high curve map)
FingerJetFX_MinutiaeQuality_8	Percentage of minutiae that have minutiae quality between 71 and 80	OrientationMap_Time	Speed computation of orientation map (without ROI filtering)
FingerJetFX_MinutiaeQuality_9	Percentage of minutiae that have minutiae quality between 81 and 90	OrientationMap_RoiFilter_Time	Speed computation of orientation map determination with ROI filtering
FingerJetFX_MinutiaeQuality_10	Percentage of minutiae that have minutiae quality between 91 and 100	QualityMapEnh_Time	Speed computation of enhanced quality map computation (enhanced low contrast map, enhanced orientation map, low flow map, high
FingerJetFX_AverageMinutiaeQuality	Arithmetic mean (average) of FJFX quality value of all minutiae	QualityMapAdv_Time	Speed computation of advanced quality map computation (enhanced low contrast map, enhanced orientation map, high curve map)
FingerJetFX_ROIBlockArea	Percentage of blocks that have at least one minutia in it (block size 32x32 pixels)	LowFlowMap_Time	Speed computation of low flow map
FingerJetFX_ROIBlockAbs	Absolute number of blocks that have at least one minutia in it (block size 32x32 pixels)	OrientationMap_RoiFilter_CoherenceSum	Sum of all blockwise coherence values based on orientation map computation (block size 16) with applied ROI filter of ImgProcROI m
FingerJetFX_MinCount_COMMinRect200x200	Number of minutiae detected in rectangle of 200x200 pixels around centre of mass (based on minutiae locations)	OrientationMap_RoiFilter_CoherenceRel	Relative number of all blockwise coherence values based on orientation map computation (block size 16) with applied ROI filter of Im
FingerJetFX_MinCount_COMMinRect300x200	Number of minutiae detected in rectangle of 300x200 pixels around centre of mass (based on minutiae locations)	OrientationMap_CoherenceSum	Sum of all blockwise coherence values based on orientation map computation (block size 16) of the whole image
FingerJetFX_MinCount_COMMinCircle200	Number of minutiae detected in a circle of diameter 200 pixels around centre of mass (base on minutiae locations)	OrientationMap_CoherenceRel	Relative number of all blockwise coherence values based on orientation map computation (block size 16) of the whole image
FingerJetFX_MinCount_COMMinCircle250	Number of minutiae detected in a circle of diameter 250 pixels around centre of mass (base on minutiae locations)	QualityMap_Foreground	Number of foreground blocks based on the quality map computation (similar but not identical to NFIQ1 quality map with block size 8)
FingerJetFX_MinCount_COMGrayRect200x200	Number of minutiae detected in rectangle of 200x200 pixels around centre of mass (based on grayvalues)	QualityMap_RelCount_1	Relative number of quality map blocks that have an assigned value of 1 (similar but not identical to NFIQ1 quality map with block size
FingerJetFX_MinCount_COMGrayRect300x200	Number of minutiae detected in rectangle of 300x200 pixels around centre of mass (based on grayvalues)	QualityMap_RelCount_2	Relative number of quality map blocks that have an assigned value of 2 (similar but not identical to NFIQ1 quality map with block size
FingerJetFX_MinCount_COMGrayCircle200	Number of minutiae detected in a circle of diameter 200 pixels around centre of mass (base on grayvalues)	QualityMap_RelCount_3	Relative number of quality map blocks that have an assigned value of 3 (similar but not identical to NFIQ1 quality map with block size
FingerJetFX_MinCount_COMGrayCircle250	Number of minutiae detected in a circle of diameter 250 pixels around centre of mass (base on grayvalues)	QualityMap_RelCount_4	Relative number of quality map blocks that have an assigned value of 4 (similar but not identical to NFIQ1 quality map with block size
FingerJetFX_Time_All	Speed computation of FJFX feature extraction (of all features within this module, including COM and ROI based features) in ms	ContrastMapEnh_HighContrastBlocks	Number of high contrast blocks according to the computation results of the enhanced contrast map
FingerJetFX_Time	Speed computation of FJFX minutiae extraction and ISO container parsing	ContrastMapEnh_AvgInhomogeneity	Average of block-wise inhomogeneity values returned by enhanced contrast map
Mu	Mu (= mean of all pixel values)	ContrastMapEnh_AvgSmoothness	Average of block-wise smoothness values returned by enhanced contrast map
MMB	Mu Mu Block (MMB) (= mean of all blockwise mean intensity values)	ContrastMapEnh_AvgUniformity	Average of block-wise uniformity values returned by enhanced contrast map
Sigma	Sigma (= standard deviation of pixel values)	ContrastMapEnh_AvgQuality	Average of block-wise quality values based on the returned inhomogeneity, uniformity and smoothness values of the enhanced contra
Mu_Time	Speed computation of Mu feature	ContrastMapEnh_Time	Speed computation of enhanced contrast map computation
MMB_Time	Speed computation of MMB feature	QualityMapEnh_HighFlowBlocks	Number of high flow blocks determined by the enhanced quality map (low flow map)
Sigma_Time	Speed computation of Sigma feature	QualityMapEnh_LowFlowBlocks	Number of low flow blocks determined by the enhanced quality map (low flow map)
ImgProcROIBlockArea	Percentage of ROI blocks in relation to all blocks of image (block size 32x32 pixels)	QualityMapEnh_Foreground	Number of foreground blocks based on the quality map computation (similar but not identical to NFIQ1 quality map with block size 8)
ImgProcROIBlockAbs	Absolute number of ROI blocks in image (block size 32x32 pixels)	QualityMapEnh_RelCount_1	Relative number of enhanced quality map blocks that have an assigned value of 1 (similar but not identical to NFIQ1 quality map with
ImgProcROIPixelArea	Absolute number of ROI pixels in image	QualityMapEnh_RelCount_2	Relative number of enhanced quality map blocks that have an assigned value of 2 (similar but not identical to NFIQ1 quality map with
ImgProcROIArea_Mean	Mean value (= Mu) of ROI blocks only	QualityMapEnh_RelCount_3	Relative number of enhanced quality map blocks that have an assigned value of 3 (similar but not identical to NFIQ1 quality map with
ImgProcROIArea_StdDev	Standard deviation (= sigma) of ROI blocks only	QualityMapAdv_RelCount_4	Relative number of advanced quality map blocks that have an assigned value of 4 (similar but not identical to NFIQ1 quality map with
ImgProcROIArea_OCL	Orientation Certainty Level (OCL) feature value of ROI blocks only	LowFlowMap24_HighFlowBlocks	Number of high flow blocks determined by the low flow map (block size 24 x 24)
ImgProcROIArea_Time	Speed computation of ImgProcROI features	LowFlowMap24_Time	Speed computation of low flow map with block size 24 x 24
ImgProcROIArea_OCL_Time	Speed computation of ImgProcROIArea_OCL feature	LowFlowMap32_HighFlowBlocks	Number of high flow blocks determined by the low flow map (block size 32 x 32)
FJFXPos_Mu_AverageMinutiaeQuality	Average minutiae quality based on mean and stddev of pixel grayvalues (=Mu) of a 32x32 pixels block around minutiae location	LowFlowMap32_Time	Speed computation of low flow map with block size 32 x 32
FJFXPos_Mu_MinutiaeQuality_0	Percentage of Mu values (as defined above) that have value <= -0.5	Gabor	Gabor feature
FJFXPos_Mu_MinutiaeQuality_1	Percentage of Mu values (as defined above) that have value > -0.5 and <= 0	Gabor_Shen	Gabor Shen feature
FJFXPos_Mu_MinutiaeQuality_2	Percentage of Mu values (as defined above) that have value > 0 and <= 0.5	LCS	Local Clarity Score (LCS) feature
FJFXPos_Mu_MinutiaeQuality_3	Percentage of Mu values (as defined above) that have value > 0.5	OCL_S	Orientation Certainty Level (OCL) feature based on Sobel filters
FJFXPos_COMMin_MMB_224	MMB value of square (size 224x224 pixels, block size 32x32 pixels) around centre of mass (based on minutiae locations)	OCL_CD	Orientation Certainty Level (OCL) feature based on centered differences
FJFXPos_OCL_AverageMinutiaeQuality	Average of minutiae quality that was computed based on the OCL value around each minutiae location	RVU_P	Ridge Valley Uniformity (RVU) feature with padding (block size 32)
		RVU_NP	Ridge Valley Uniformity (RVU) feature without padding (block size 32)
		OF	Orientation Flow (OF) feature
		RPS	Radial Power Spectrum (RPS) feature
		FDA	Frequency Domain Analysis (FDA) feature

# Feature selection


Predictive power of each feature

Correlations among features

Random Forest variable importance



MeanDecreaseAc




MeanDecreaseAc



MeanDecrease

# NFIQ 2.0 Features



Minutia Count: Percentage of minutiae with quality values between 80 and 100, where quality is based on OCL value around each minutiae location + # of minutiae in circle radius 200 pixels around center of mass (based on minutiae locations) . (Takes about 25-45 msec)

Ridge Valley Uniformity (R-40VU) :: a measure of the consistency of the ridge and valley widths computed on block sizes 32 x 32 with padding. (~10-30 msec)

Orientation map :: Sum of all blockwise coherence values based on orientation map computation (block size 32) with applied ROI filter of ImgProcROI module (<10 msec)

Radial Power Spectrum (RPS) :: a measure of maximal signal power in a defined frequency band of the global radial Fourier spectrum only computed on rectangle around determined ROI (block size 32 x 32)

Mean value (= Mu) of ROI blocks only (< 2msec)

Number of high flow blocks determined by the low flow map (block size 32 x 32) but only computed on ROI

Local Clarity Score (LCS) (15-40 msec)

# Example

## High Q




FingerJetFX\_MinCount\_COMMinCircle200 28  
FingerJetFX\_MinCount\_COMMinRect300x200 48  
FJFXPos\_OCL\_MinutiaeQuality\_80 0.240385  
ImgProcROIArea\_Mean 164.404  
OrientationMap\_ROIFilter\_CoherenceSum  
510.051  
LowFlowMap16\_ROIArea\_HighFlowBlocks 778  
RVU\_P 0.718696  
RPS\_ROIArea 7289.66  
LCS 0.749187  
OF 0.744374  
OCL\_CD 0.68845

## Low Q



FingerJetFX\_MinCount\_COMMinCircle200 100  
FingerJetFX\_MinCount\_COMMinRect300x200 170  
FJFXPos\_OCL\_MinutiaeQuality\_80 0.079  
ImgProcROIArea\_Mean 133.12  
OrientationMap\_ROIFilter\_CoherenceSum  
110.544  
LowFlowMap16\_ROIArea\_HighFlowBlocks 227  
RVU\_P 1.531  
RPS\_ROIArea 3928.33  
LCS 0.604  
OF 0.7602  
OCL\_CD 0.5653





## MACHINE LEARNING

We examined:  
Random forest  
Support vector machine  
K-nearest neighbor

# Machine Learning

## Random Forest

- » Ensemble classifier using stochastic process
  - Use vote to determine class memberships
  - Provides class probability in predictions
  - Analysis of features importance and their ranking
    - We used this to do our final feature selection

## Two class prediction

- » High vs. Low performers
  - 1: High performers are images that result in high genuine scores and have NFIQ1=1 with activation score  $> 0.7$ .
    - $\text{genscore} > \text{CDF}^{-1}(0.9)$  &  $\text{NFIQ1.0} = 1$
  - 0: Low performers are images that result in false reject and have NFIQ 1.0=5 with activation score  $> 0.9$ .
    - FRR at Threshold at  $\text{FMR}=0.0001$
  - Training data: intersection of images in Class 0 (or Class 1) across all providers
  - Quality score is the probability that a given image belongs to class 1.
- » Map quality score to recognition rate.

## Training


Features: image processing + #minutiae + minutiae quality  
~3500 samples in each of the low and high performers classes  
1000 trees in forest

## Test


75000 comparison scores

# So, DOES IT WORK?


# genuine score vs. NFIQ 2.0 score




# NFIQ 2.0 vs genuine score



# NFIQ 2.0 performance



Verification Random Forest



Enrolment Random Forest

# NFIQ 2.0 computation time

## Lite (SOM)

- » ~ 65 ms/image
  - PC - 2.3 GHz Intel Core i7
  - 16 GB of memory.
  - network size of dim = 24
  - block size of  $n = 24$
  - With gray scale normalization
- » ~ 82 ms/image.
  - PC - 2.3 GHz Intel Core i7
  - 16 GB of memory.
  - network size of dim = 24
  - block size of  $n = 64$
- » This is prior to any code optimization

## NFIQ 2.0 (29 features)

- » < 150 msec/image
  - Upper bound using 29 features
  - Expect great improvement with 8 or 11 features
  - Standard 3 years old laptop
- » This is prior to complete code optimization

**ACTIONABLE QUALITY**



# Actionable quality

## Feed back to user/operator

- » Wet / dry
  - High/low pressure
    - MS Thesis (M. Dusio, C. Busch)
- » Centeredness
  - Singularity detection
- » Incompleteness
  - Entropy of orientation flow
- » Ghost images



## Questions?

- » Sensor sensitivity?
- » Algorithm sensitivity?
- » Already covered by features?
- » Any addition or deletion?
  - Fingerness?
  - Alteredness?
  - correctness of phalanx?

# Current Status

## Completed

- » Framework design
  - Modular, plug and play
- » Framework implementation
- » Feature selection and prototype implementation complete
  - [http://biometrics.nist.gov/cs\\_links/quality/NFIQ\\_2/NFIQ-2\\_Quality\\_Feature\\_Defin-Ver05.pdf](http://biometrics.nist.gov/cs_links/quality/NFIQ_2/NFIQ-2_Quality_Feature_Defin-Ver05.pdf)
- » Feature evaluation complete.
- » Feature Implementation - MATLAB to C/C++
  - Thanks to FBI + MITRE
- » Exploring machine learning
  - Random forest, SVM.
- » Feature selection (almost – contingent on their computation time).
- » Implementation of actionable flags for detection and mitigation of bad presentations
  - Incomplete finger (tip, etc.) + Wet / dry + Pressure

## Underway

- » Beta testing of NFIQ 2.0
  - BKA Data + FpVTE data
  - Finalizing training
- » NFIQ 2.0 Lite
  - Self organizing map or just efficient features?
- » Evaluation of Implementation of actionable flags for detection and mitigation of bad presentations
  - Incomplete finger (tip, etc.) + Wet / dry + Pressure
  - But, tricky – since we do not have ground-truth for this.
- » Conformance Suite
- » Mapping of NFIQ 2.0 → NFIQ 1.0

# NFIQ 2.0

## Promises, promises

- » Improved feature
- » More level (0-100)
- » Faster, lighter
- » Actionable feedback
- » NFIQ 2.0 mobile
- » Slap
- » Better performance
- » Modular design
- » Calibration
- » Conformance testing

## So far, we have achieved

- » Many features, somehow improved
- » More level (0-100)
- » Faster, lighter
- » Actionable feedback
- » Towards NFIQ Mobile
- » --
- » Better performance – we hope
- » Plug and play
- » Mapping to FNMR
- » Underway
- » Standard features

ISO/IEC 29794

ANSI/NIST-ITL

# STANDARDIZATION

# Standardisation - then

## ISO/IEC IS 29794-1:2009

- » Information technology -  
Biometrics sample quality Part 1:  
Framework
- » Definitions
  - quality: "the degree to which a biometric sample fulfils specified requirements for a targeted application"
  - quality score: "a quantitative expression of quality"
  - utility: "the observed performance of a biometric sample or set of samples in one or more biometric systems"
- » Quality score from 0 to 100

## 5-byte Quality Block

description		size	valid values	notes
Number of Quality Blocks		1 byte	[0,255]	This field is followed by the number of 5-byte Quality Blocks reflected by its value (see Fehler! Verweisquelle konnte nicht gefunden werden.). A value of zero (0) means that no attempt was made to assign a quality score. In this case, no Quality Blocks are present.
Quality Block	Quality Score	1 byte	[0,100] 255	0: lowest 100: highest 255: failed attempt to assign a quality score
	Quality Algorithm Vendor ID	2 bytes	[1,65535]	Quality Algorithm Vendor ID shall be registered with IBIA as a CBEFF biometric organization. Refer to CBEFF vendor ID registry procedures in ISO/IEC 19785-2.
	Quality Algorithm ID	2 bytes	[1,65535]	Quality Algorithm ID may be optionally registered with IBIA as a CBEFF Product Code. Refer to CBEFF product registry

# Standardization - now

## ISO/IEC 29794-1:201X

- » Information technology - Biometrics sample quality Part 1: Framework
- » Definitions
  - Same as before, but allow for a vector of quality components
  - Goal: Actionable quality
- » Each element of quality vector has a score from 0 to 100.

## Vector of quality components


Table 2 – Data fields

		Description	Size	Valid values	Notes
		Number of Quality Blocks (N)	1 byte	0 to 255	This field is followed by the number of 5-byte Quality Blocks reflected by its value. A value of zero (0) means that no attempt was made to assign a quality score. In this case, no Quality Blocks are present.
Quality Block 1	Byte 1	Quality Indicator	1 byte	0 to 100 250 255	0 to 100: the encode value is the overall quality score of the representation. It should express the predicted recognition performance of a representation with higher values indicating better quality. 250 (FA <sub>Hex</sub> ): a vector of quality metrics is encoded in bytes 6-N. 255 (FF <sub>Hex</sub> ), an attempt to calculate a quality score has failed
	Bytes 2-3	Quality Algorithm Vendor ID	2 bytes	1 to 65535	Quality Algorithm Vendor ID shall be registered with IBIA as a CBEFF biometric organization. Refer to CBEFF vendor ID registry procedures in ISO/IEC 19785-2.
	Bytes 4,5	Quality Algorithm ID	2 bytes	1 to 65535	Quality Algorithm ID shall be registered with IBIA as a CBEFF biometric organization. Refer to CBEFF vendor ID registry procedures in ISO/IEC 19785-2.
Bytes 6 – 5 x (Number of quality blocks) exist only if quality indicator (Byte 1) is 250 (FA <sub>Hex</sub> ).					
Quality Blocks 2-N	6	Overall quality score	1 byte	0 to 100	A quality score should express the predicted comparison performance of a representation. A quality score shall be encoded in one byte as an unsigned integer. Allowed values are 0 to 100 with higher values indicating better quality
	7	Number of quality vector elements	1 byte	Defined in each Part of this Standard	If the number of quality vector elements mod 5 is not equal to three then padding bytes should be added such that the length of the block is a multiple of five. This will ensure backward compatibility with the implementations conformant with ISO/IEC 29794-1:2009 and ISO/IEC 19794-x:2011. For example, if the number of quality vector elements is 14, 4 padding bytes shall be added so that the length of the image quality record is 25 = 4(padding) + 14(number of quality vector elements) + 7(as shown in rows 1-7).
	8	Quality metrics			As defined in modality specific parts of this International Standard.

# Support standardization of finger image quality

## ISO/IEC 29794-4

- » Provide quantitative support to development of Information technology — Biometric sample quality — Part 4: Finger image
  - Currently at 2nd working draft
- » Contribute feature computation method + codes
  - Allows for plug-and-play of features for implementations that satisfy semantic conformance to the requirements of the ISO/IEC 29794-4 standard




**NFIQ 2.0 LITE (MOBILE)**



# NFIQ 2.0 Lite/Mobile

## Requirements

- » Low computation complexity
  - processing power
  - Processing time
- » Therefore, feature computation not feasible!
- » Look up table?




## SOM

- » Unsupervised clustering (unlabelled training data)
- » Training phase
  - Iteratively present training vectors to build clusters (codebook vectors)
- » Prediction phase
  - Input vector is assigned a class based on distance to learned clusters
- » Topology preserving - similar classes will have similar spatial locations in the map


# Self organizing maps

M. Olsen, E. Tabassi, A. Makarov, C. Busch: „Self-Organizing Maps for Fingerprint Image Quality Assessment“, in Proceedings of the 26th Conference on Computer Vision and Pattern Recognition (CVPR 2013), June 23-28, Portland, Oregon, (2013)





# SOM unsupervised training



Iteration: 0

Iteration: 0

SOM Ordering Phase


# Self organizing maps for NFIQ2.0 Lite-1



Divide fingerprint image into blocks and look up nearest cluster to get a label

A	A	A	A	A
A	B	C	D	A
A	E	C	D	A
A	E	C	C	A

Finger image is transformed into cluster histogram




Quality Score



Random Forest

# NFIQ 2.0 Lite prototype

## Features



## performance





## NIST Biometric Quality Program

### Push Towards Zero Error Biometrics

<b>Strengthening Science</b> Failure Analysis Identifying the likely causes of recognition error, quantifying their effect and ways to mitigate them.	<b>Advancing metrology</b> Performance Evaluation Quantitative means of assessing performance of quality assessment algorithms (IREX II IQCE)	<b>Developing Standards</b> Requirements Specifications On image properties affecting performance, and on capture device	<b>Developing Tool Box</b> Open source Public domain Reference implementations of quality assessment algorithm, iris segmentation	<b>Best Practice Guidance</b> Instructional + Guidance Materials for quality score summarization + Best capture practice + example images of various quality	<b>Enumerative Bibliography</b> Technical Literature Reports, white papers, publications relevant to biometric quality and iris image quality in particular	<b>Coordination+ Collaborations</b>  Workshops, Conferences Grants (WVU, NYU Poly)
<b>Research</b>	<b>Evaluation</b>	<b>Standard</b>	<b>Software</b>	<b>Report</b>	<b>Webpage</b>	
NIST IR 7155 ICIP 2005 NIST IR 7820	NIST IR 7820 PAMI 2007 ICPR 2010	ISO/IEC 29794 ISO/IEC 19794	NFIQ 1.0 NFIQ 2.0 NIIQ 1.0	NIST IR 7422 NIST IR 8XXX	<a href="http://www.nist.gov/itl/iad/ig/bio_quality.cfm">www.nist.gov/itl/iad/ig/bio_quality.cfm</a>	BQW 2006, 07 IBPC 2010, 12 NFIQ 2010,12

# Thank You.

Elham Tabassi  
 301 975 5292  
[tabassi@nist.gov](mailto:tabassi@nist.gov)