

---

## **9. Water and Wastewater Systems**

---

### **9.1. Introduction**

Water and wastewater systems represent essential infrastructure for sustaining the economic and social viability of a community. Although these systems provide basic public health and safety to homes, businesses, and industry, they are often taken for granted because of the high level of service and reliability provided by water and wastewater utilities. The importance of these systems is not recognized until a water main break or other disruption in service occurs. This chapter addresses disaster resilience of public water and wastewater systems.

While some utilities are already taking steps to improve the resilience of their systems, capital improvement programs and many others often focus on performing emergency repairs, increasing system capacity to meet population growth, or making system improvements to satisfy public health and environmental regulations. Replacing buried pipelines is often delayed until water main breaks become frequent or wastewater pipeline groundwater infiltration rates create excessive demand on the treatment system. Communities have a perfect opportunity to couple resilience with future/planned retrofits or replacements of old infrastructure, to improve the resilience of water and wastewater infrastructure. This chapter focuses on the water and wastewater infrastructure itself. However, the water and wastewater industry faces challenges beyond just the infrastructure performance. Water quality and environmental impact are two of the biggest concerns. For example, if water of poor quality is delivered to customers, there is significant risk that the public may become ill from consumption. The wastewater industry operates within strict environmental constraints that have and will likely continue to become more stringent. These restrictions prevent excessive pollution that contribute to environmental damage and, ultimately, impact the health of the humans and animals. Although this chapter touches on such challenges, its main focus is how to build a more resilient infrastructure system that will deliver good quality water with fewer disruptions and limit damage to wastewater systems, making spills less frequent.


#### **9.1.1. Social Needs and Systems Performance Goals**

Water services are essential to our daily lives. Using USGS data, Aubuchon & Morley (2012) calculated the average consumption of water across all U.S. states to be 98 gallons per person per day. However, water consumption varies by community and by customer. Personal uses include water for drinking and cooking, personal hygiene, flushing toilets, laundry, landscape irrigation, and many others. Many businesses and industries also depend on a continual supply of potable water and wastewater collection services. Absent functioning drinking water and wastewater systems, the operation of restaurants, child care facilities, hotels, medical offices, food processing plants, paper mills, etc., significantly compromised, if not completely impossible. Additionally, water systems in urban and suburban areas provide water supply for fire suppression. Chapter 2 discusses this societal dependence on water and wastewater systems and other infrastructure systems in more detail.

In the United States, communities generally accommodate to short-term (on the order of a few days) disruptions in water and wastewater services resulting from man-made or natural hazard events. However, longer-term disruptions are less tolerable. The Oregon Resilience Plan (OSSPAC, 2013) indicated a business that cannot reoccupy facilities (including functioning water and wastewater systems) within one month would be forced to move or dissolve. This timeline likely varies depending on community needs and the severity of the event. Water and wastewater utility providers need to work with customers and regulatory agencies to establish realistic performance goals for post-disaster level of service, evaluate their systems' status in relation to those goals, and then develop strategies to close the identified resilience gaps. Flow, pressure, and water quality should be considered in those performance goals.

45 **9.1.2. Interdependencies**

46 As discussed in Chapter 4, water system operations are interdependent with other infrastructure systems,  
 47 both for day-to-day operation and restoration following a hazard event. Electric power is one of the most  
 48 important services necessary for maintaining pumping and treatment operations. Transportation is critical  
 49 to allow access for inspection and repairs after the event, as well as maintaining the supply chain. Figure  
 50 9-1 presents some interdependencies of the water infrastructure system with other infrastructure systems.



51  
 52 **Figure 9-1. Water Interdependencies with Other Infrastructure Systems (Morley 2013)**

53 Some of the most important dependencies for the water and wastewater infrastructure systems include:

- 54 1. **Energy/Power (Electric and Fuel/Petroleum)** – Water and wastewater utilities rely on  
 55 commercial electricity to run pumps, treatment processes, and lab and office operations. Some of  
 56 these functions may have standby power, but overall power demands make it impractical for most  
 57 water and wastewater systems to run entirely on standby generators. However, short-term power  
 58 loss events are often mitigated by standby generators supported to maintain water and wastewater  
 59 operations. These emergency conditions are dependent on sustained fuel supply for standby  
 60 generators to support utility vehicles and equipment. Disruption in fuel production, storage, or  
 61 delivery may severely impact a water utility’s ability to sustain operations on standby generator  
 62 power and perform repairs.
- 63 2. **Transportation (Staff, Supplies, Pipelines)** – Staff at water and wastewater facilities depend on  
 64 roadway and bridge transportation systems for access. Damage to transportation infrastructure  
 65 potentially complicates and lengthens repair times or even prevents repairs until roadways and  
 66 bridges are usable. Water and wastewater utilities generally keep a limited stock of pipe, fittings,  
 67 and other repair materials to use in response and recovery operations. However, depending on the  
 68 size of the event, this stock may be quickly depleted due to supply chain disruptions. Such  
 69 disruptions may also impact the available support from relief equipment and personnel. Utilities  
 70 also rely on a semi-regular delivery of treatment process chemicals essential for meeting water  
 71 quality regulations.

## DISASTER RESILIENCE FRAMEWORK

75% Draft for San Diego CA Workshop

11 February, 2015

### Water and Wastewater Systems, Water and Wastewater Infrastructure

---

72 Water and wastewater buried pipelines are often co-located with other buried infrastructure under  
73 or adjacent to roadways. Failure of pipelines may result in damage to the roadway (e.g., sinkhole  
74 from water main break or collapsed sewer pipeline) and impact to traffic during repairs.  
75 Therefore, the transportation system, particularly the roadway system, is dependent on the  
76 performance of the water and wastewater infrastructure systems.

77 3. **Communications and Information** – Water and wastewater utilities often rely on cellular  
78 networks to communicate to operations staff and contractors. If the cellular network is down for  
79 an extended period, complications and delays in repairs can occur. Additionally, supervisory  
80 control and data acquisition (SCADA) networks are used extensively within both water and  
81 wastewater systems to monitor and control widespread components and equipment.

82 The communications system infrastructure also depends on water infrastructure. For example, air  
83 conditioning system cooling towers that support communications require water to keep sensitive  
84 electronic equipment in Central Offices at safe operating temperatures. Furthermore, technicians  
85 cannot enter Central Offices to maintain or repair functionality of the communications system if  
86 its water and wastewater systems are not functioning.

87 4. **Buildings (Critical, Commercial, General Public)** – Water and wastewater utilities rely on  
88 customers (e.g., critical facilities, commercial facilities, and households) to pay bills as a  
89 continued source of capital. Utilities will potentially experience significant capital expenditures in  
90 the aftermath of a disaster and customers may not have the ability to pay bills (i.e., loss of  
91 personal income from loss of wages or breakdown of electronic or posted payments), placing a  
92 large financial burden on the utilities. Water and wastewater utilities also operate administrative  
93 buildings. New Orleans Water & Sewer Board’s treatment, distribution, collection, and  
94 administrative operations were severely impacted following Hurricane Katrina. The  
95 administration’s disruptions included the loss of customer billing and other records due to  
96 significant flooding. During this same event, Children’s Hospital of New Orleans was forced to  
97 evacuate when the hospital lost water pressure and was unable to maintain the HVAC system  
98 needed by patients in critical care units.

99 Commercial and other public buildings need water supply with adequate flow and pressure for  
100 fire suppression, as well as sanitation. Industrial facilities need functional water and wastewater  
101 systems for developing, processing, and manufacturing materials and products. The public relies  
102 on water and wastewater services for overall health of the community.

## 103 9.2. Water and Wastewater Infrastructure

104 This section describes basic components of water and wastewater systems. Performance observations  
105 from past disaster events characterize some key hazard vulnerabilities in water and wastewater systems.  
106 Water and wastewater infrastructure are vulnerable to a number of hazards: buried pipelines are  
107 vulnerable to breaks during earthquakes, water and wastewater treatment facilities are vulnerable to flood  
108 hazards. Facilities are often designed to be in or near flood hazard areas, given their functional  
109 dependency on natural water resources. To become more resilient, each individual community will have  
110 to consider its own hazards when implementing plans. Additionally, as discussed in the previous section,  
111 system interdependencies (e.g., loss of commercial electrical power in a high wind event) can have a  
112 significant impact on operability of water and wastewater systems (Elliott, T. and Tang, A., 2009).

### 113 9.2.1. Water Infrastructure

114 Water sources include groundwater and surface water, treated to satisfy public health standards and  
115 distributed to consumers by a network of pipelines. Some water utilities have their own supplies and  
116 treatment infrastructure, while others buy wholesale water from neighboring agencies.

117 Water systems are composed of six general infrastructure categories: 1) Supply, 2) Transmission, 3)  
118 Treatment, 4) Pumping, 5) Storage, and 6) Distribution. The basic function of each category and

**DISASTER RESILIENCE FRAMEWORK**  
**75% Draft for San Diego CA Workshop**  
**11 February, 2015**

**Water and Wastewater Systems, Water and Wastewater Infrastructure**

119 infrastructure system (electric power, transportation, communication) interdependent of the water system  
 120 can be impacted by a variety of hazards, as shown in Table 9-1. Some examples of damage to water  
 121 infrastructure seen in past events are discussed in the following subsections.

122 *Table 9-1. Hazard Impacts on Water Infrastructure System (AWWA M19: Emergency Planning for*  
 123 *Water Utilities)*

System Components – Likely damage, loss, or shortage due to hazards	Earthquakes	Hurricanes	Tornadoes	Floods	Forest or Brush Fires	Volcanic eruptions	Other Severe Weather	Waterborne Disease	Hazardous Material	Structure Fire	Construction Accidents	Transportati on Accidents	Nuclear	Vandal, riots, Strikes
Administration/operations														
Personnel	♦	♦					♦	♦			♦	♦	♦	♦
Facilities/equipment	♦	♦	♦	♦	♦	♦				♦			♦	♦
Records	♦	♦	♦	♦	♦	♦							♦	♦
Source Water														
Watersheds/surface sources	♦	♦		♦	♦	♦		♦	♦				♦	♦
Reservoirs and dams				♦	♦	♦		♦	♦				♦	♦
Groundwater sources	♦	♦	♦			♦	♦	♦	♦					♦
Wells and galleries														
Transmission														
Intake structures	♦		♦	♦		♦	♦					♦		♦
Aqueducts	♦			♦		♦	♦				♦	♦		♦
Pump stations	♦		♦	♦		♦	♦			♦	♦	♦		♦
Pipelines, valves	♦	♦												♦
Treatment														
Facility structures	♦	♦	♦	♦	♦	♦	♦			♦	♦	♦	♦	♦
Controls	♦	♦	♦	♦	♦	♦	♦			♦	♦	♦	♦	♦
Equipment	♦	♦	♦	♦	♦	♦	♦			♦	♦	♦	♦	♦
Chemicals	♦	♦	♦	♦	♦	♦	♦			♦	♦	♦	♦	♦
Storage														
Tanks	♦	♦	♦		♦	♦	♦	♦	♦	♦		♦	♦	♦
Valves	♦	♦	♦		♦	♦	♦	♦	♦	♦		♦	♦	♦
Piping	♦	♦	♦		♦	♦	♦	♦	♦	♦		♦	♦	♦
Distribution														
Pipelines, valves	♦	♦		♦	♦	♦	♦	♦	♦	♦	♦	♦		♦
Pump or PRV stations	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦		♦
Materials	♦	♦		♦	♦	♦	♦	♦	♦	♦	♦	♦		♦
Electric power														
Substations	♦	♦	♦	♦	♦	♦	♦			♦	♦	♦	♦	♦
Transmission lines	♦	♦	♦	♦	♦	♦	♦			♦	♦	♦	♦	♦
Transformers	♦	♦	♦	♦	♦	♦	♦			♦	♦	♦	♦	♦
Standby generators				♦						♦	♦	♦	♦	♦
Transportation														
Vehicles		♦	♦	♦	♦	♦	♦				♦	♦		♦
Maintenance facilities	♦	♦	♦	♦	♦	♦	♦			♦	♦	♦		♦
Supplies		♦	♦	♦	♦	♦	♦			♦	♦	♦		♦
Roadway infrastructure	♦			♦		♦	♦				♦	♦		♦
Communications														
Telephone	♦	♦	♦	♦	♦	♦	♦			♦	♦	♦		♦
Two-way radio	♦	♦	♦	♦	♦	♦	♦			♦	♦	♦		♦
Telemetry	♦	♦	♦	♦	♦	♦	♦			♦	♦	♦		♦

124  
 125 **9.2.1.1. Supply**

126 Water supply can come from groundwater or surface water, as described below.

127 **Groundwater.** Rainfall and snowmelt infiltrate into the ground to recharge groundwater aquifers.  
 128 Groundwater wells tap into aquifers and supply water to individual households or municipal water  
 129 providers. A well system consists of the groundwater aquifer, well casing and screen, pump and motor,  
 130 power supply, electrical equipment and controls, connecting piping, and possibly a well house structure.  
 131 Typically, wells are cased with a steel pipe. Screens in the well casing at the depth of the aquifer allow  
 132 water to enter the casing. A submersible or surface-mounted pump conveys water to the transmission  
 133 system.

134 **Surface Water.** Rainfall and snowmelt runoff that does not infiltrate into the ground collects in streams,  
 135 rivers, and lakes, and is sometimes impounded by dams. Water intake structures in lakes or rivers and  
 136 diversion dams then direct water to a pipeline inlet along the shoreline. All of these systems would  
 137 generally include screens to keep large debris and fish from entering the treatment plant.

138 Just as with water and wastewater infrastructures, the water supply is particularly vulnerable flooding and  
 139 earthquakes. The most significant hazard is contaminated water; flooding can cause contamination of  
 140 surface and groundwater sources. Additionally, inundated well heads at the surface can introduce

## DISASTER RESILIENCE FRAMEWORK

75% Draft for San Diego CA Workshop

11 February, 2015

### Water and Wastewater Systems, Water and Wastewater Infrastructure

---

141 contaminants to well systems and groundwater. Floodwaters and generally carry contaminants like  
142 petroleum, nutrient/organic matter, bacteria, protozoa, and mold spores that pose significant health risks.  
143 Contamination can also result from tank or vehicle discharge in the watershed. In 2014, in West Virginia,  
144 4-methylcyclohexanemethanol (MCHM) was released into the Elk River, contaminating water serving  
145 300,000 people. It took months to restore full water service.

146 Although not often considered for their impact on water quality, wildfires can also lead to water  
147 contamination. Wildfires can burn watersheds, destabilizing the ground cover, which can cause landslides  
148 that contaminate the water when subsequent rains occur. Denver Water experienced wildfires in  
149 significant parts of their watershed in 1996 and 2002 that burned 150,000 acres of land, releasing one  
150 million cubic yards of sediment into one of their reservoirs.

151 Reservoirs behind dams often also serve as water supply features, but dam failure can present a secondary  
152 hazard in the wake of earthquakes, heavy rainfall, and flood events. Concentrated precipitation and  
153 flooding most commonly causes overtopping of the dam. While dams can reduce flooding, older and  
154 improperly designed and maintained dams are not equipped to contain large volumes of quickly  
155 accumulating water runoff. Landslides, caused by liquefaction from earthquakes can also lead to dam  
156 failure. These types of dam failures are rare, but present a significant risk to anyone's life downstream of  
157 a dam. Dams are critical infrastructure components that need to be designed to withstand extreme events.

#### 158 **9.2.1.2. Transmission**

159 Large diameter transmission pipelines carry raw water  
160 from source to treatment plant, and treated water to  
161 storage facilities before branching out into smaller  
162 distribution pipelines. Depending on the system, these  
163 can range from one foot to several tens of feet in  
164 diameter. Transmission pipelines are constructed of  
165 welded steel, reinforced concrete, concrete cylinder, or  
166 ductile iron (historically cast iron).

167 Typically, these pipelines are buried, making them  
168 difficult to inspect and expensive and disruptive to  
169 repair. Burial reduces pipelines' vulnerability to  
170 hazards, such as high wind events; however, hazards  
171 that cause landslides, such as earthquakes, floods,  
172 long-term heavy rain, and wildfire, can damage  
173 transmission lines. Figure 9-2 shows a transmission  
174 pipeline bridge demolished in the Bull Run Canyon in  
175 a landslide event induced by heavy rains.



*Figure 9-2. Water Transmission Pipeline Bridge Damaged by Landslide (Courtesy of Portland Water Bureau)*

#### 176 **9.2.1.3. Treatment**

177 Water treatment plants process raw water from groundwater or surface water supplies to meet public  
178 health water quality standards and often to improve taste. The processes used depend on the raw water  
179 source, removing pathogens, organic or inorganic contaminants, chemicals, and turbidity. The treatment  
180 process commonly includes pretreatment, flocculation, sedimentation, filtration, and disinfection with  
181 variations of these processes in some modern plants. Water treatment plants typically consist of a number  
182 of process tanks, yard and plant piping, pumps, chemical storage and feed equipment, lab and office  
183 building space, and associated mechanical, electrical, and control equipment.

184 Water treatment plants are vulnerable to flooding, because they are often located near flooding sources  
185 (i.e., lakes, rivers). Electrical control systems are often damaged by flood inundation, leading to loss of  
186 functionality and service outages. In 1991, the Des Moines, Iowa Water Treatment Plant was submerged  
187 by riverine flooding, resulting in 19 days without potable water for the city of Des Moines.

188 Loss of power at water treatment plants from high wind events (hurricanes, tornadoes), severe storms, or  
189 other hazards can severely impact the system by preventing proper treatment prior to transmission and  
190 distribution. As a result, potable water may not be available and boil water notices necessary. While  
191 standby power systems are usually incorporated into a water treatment plant's design, they need to be  
192 well-maintained, tested regularly, and adequately connected, installed, supplied, and protected from  
193 hazard events to be reliable and function properly.

194 Earthquakes also cause damage to water treatment plants and their components. In 1989, the Loma Prieta  
195 earthquake in California heavily damaged the clarifiers due to sloshing water at the Rinconada Water  
196 Treatment Plant in San Jose, California, greatly curtailing its 40 MGD capacity (Figure 9-3). In the 2011  
197 Tohoku earthquake in Japan, liquefaction resulted in differential settlement between pile-supported  
198 structures and direct-buried pipe at water treatment plants, as shown in Figure 9-4.



*Figure 9-3. Santa Clara Valley Water District, Rinconada Water Treatment Plant Clarifier Launderers Damaged due to Sloshing, 1989 Loma Prieta Earthquake (Courtesy of Don Ballantyne)*



*Figure 9-4. Liquefaction Caused Differential Settlement Between Pile-Supported Structures and Buried Pipe during the 2011 Tohoku Earthquake (Courtesy of Don Ballantyne)*

199 **9.2.1.4. Pumping**

200 Pumping stations increase hydraulic head (i.e., raise water from one elevation to a higher elevation). A  
201 pump station typically consists of a simple building that houses pumps, motors that power the pumps,  
202 pipes, valves, and associated mechanical, electrical, and control equipment. Pump stations often have  
203 standby emergency generators to enable continued operation when commercial power supply is  
204 interrupted.

205 Similarly to water treatment plants, loss of  
206 commercial electrical power due to any type of  
207 hazard event prevents operation of pumps if there  
208 is no standby power supply. Furthermore,  
209 floodwater can inundate electrical equipment and  
210 controls at pump stations located wholly or  
211 partially below grade and/or in flood-prone areas.  
212 Figure 9-5 shows a pump station adjacent to the  
213 Missouri River damaged by flood inundation.



*Figure 9-5. Bismarck, ND Pump Station Damaged by Flood Inundation from Adjacent Missouri River (Courtesy of FEMA)*

214 **9.2.1.5. Storage**

215 Water utilities use storage tanks and reservoirs to  
216 balance water demand with water production  
217 capacity. Stored potable water is drawn down  
218 during times of peak usage and recharged during  
219 off-peak hours. Typically, one to three days of

Water and Wastewater Systems, Water and Wastewater Infrastructure

220 daily water demand is stored to satisfy increased demand from fire suppression or other emergency needs.  
221 Reservoirs are often constructed by damming a valley with a concrete or earthen dam. If they are being  
222 used for treated water, they can be lined with asphalt or concrete and covered.

223 Modern steel storage tanks are either ground-supported, taller standpipes, or elevated tanks supported on a  
224 frame or pedestal. Reinforced concrete tanks are typically at grade or buried. Circular concrete tanks can  
225 be reinforced with wire wrapping or tendons.

226 Storage tanks are vulnerable to a number of  
227 hazards. Elevated storage tanks are more  
228 susceptible to hazards from high winds than  
229 structures located at grade and can be damaged to  
230 the point of structural failure, suddenly releasing  
231 their contents. In hurricanes, high winds present a  
232 higher hazard in coastal areas (than further  
233 inland) and are often accompanied by storm  
234 surge. Figure 9-6 shows a collapsed water tank in  
235 Buras, Louisiana near Hurricane Katrina's  
236 landfall that was likely caused by a combination  
237 of high winds and storm surge.



*Figure 9-6. Collapsed Water Tank in Buras, LA near Hurricane Katrina Landfall Location (Courtesy of David Goldbloom- Helzner)*

238 At-grade or partially-underground storage tanks  
239 are more susceptible to flood damage (from  
240 hurricane storm surge, riverine flooding, or  
241 tsunamis), particularly if located in or near flood-  
242 prone areas. Tank damage or failure can be  
243 caused by both hydrostatic forces from standing  
244 or slow moving water, or hydrodynamic forces  
245 imposed by higher velocity flows or wave action.  
246 Buoyancy forces can cause uplift of empty  
247 subgrade tanks if the soil becomes saturated.  
248 Figure 9-7 shows two liquid fuel tanks in the  
249 foreground that were floated and toppled by  
250 tsunami wave inundation after the 2011 Tohoku,  
251 Japan tsunami. The tank in the background was  
252 on higher ground and does not appear to be  
253 damaged.



*Figure 9-7. Steel Tanks Damaged Due to Tohoku, Japan Tsunami in 2011 (Tang & Edwards 2014)*

254 Earthquakes can damage storage tanks due to  
255 lateral loads (shaking) and permanent ground  
256 deformation due to liquefaction and landslides. Water sloshes in storage and process tanks imparting  
257 extreme loads on tank walls and baffles. In the 1994 Northridge earthquake, a Los Angeles Department of  
258 Water and Power (LADWP) tank moved, severing piping, as shown in Figure 9-8. The utility just north  
259 of LADWP suffered elephant's foot buckling in a steel tank as shown in Figure 9-9.

260



*Figure 9-8. Tank Moved, Severing Connecting Pipe in 1994 Northridge Earthquake (Courtesy of Los Angeles Department of Water and Power)*



*Figure 9-9. Steel Tank “Elephant’s Foot” Buckling in 1994 Northridge Earthquake (Courtesy of Donald Ballantyne)*

261 **9.2.1.6. Distribution**

262 Smaller diameter distribution pipelines carry treated water from transmission pipelines to neighborhoods  
263 commercial and industrial areas. Service connections with meters branch off distribution pipelines to  
264 supply individual customers. The portion of the service connection before the water meter is typically  
265 maintained by the water utility and the portion after the water meter is the responsibility of the individual  
266 customer. The system is controlled with manually operated valves distributed at most pipeline  
267 intersections. Distribution systems have fire hydrants located every 300 feet along the pipeline.  
268 Distribution pipelines are commonly made with ductile iron (historically cast iron), welded steel, PVC, or  
269 asbestos cement.

270 Leaks and breaks are two main concerns for distribution pipelines. A leak commonly refers to relatively  
271 minor damage to a pipe barrel or joint that causes minor to moderate water loss, but does not significantly  
272 impair the distribution system’s function. However, breaks commonly refer to major damage to a pipe  
273 barrel or joint that causes major water and pressure loss in a zone or drains nearby tanks. When there are  
274 breaks in the water distribution system, it can lead to depressurization of the system. Depressurization can  
275 result in sediment accumulation within the pipelines affecting the potability of the water, contamination  
276 and loss of potability means boil water orders should be issued. Before water can be considered potable  
277 again, the distribution systems must be fixed and the water quality monitored and tested continuously to  
278 meet public health standards.

279 Breaks of distribution pipelines can result from a number of hazards. Floods cause erosion, exposing,  
280 possibly breaking pipelines (see Figure 9-10).



*Figure 9-10. Exposed and Broken Distribution Lines Resulting from Flooding in Jamestown, CO (Courtesy of David Goldbloom-Helzner)*

281 Earthquakes can cause liquefaction or permanent  
282 ground deformation, causing pipeline breaks. In the  
283 1994 Northridge earthquake, the Los Angeles  
284 Department of Water and Power had approximately  
285 1,000 pipeline breaks, primarily in cast iron pipe.  
286 While there was only limited liquefaction, ground  
287 motions were very strong. A year later, the Kobe  
288 earthquake caused approximately 1,200 pipeline  
289 failures due to extensive liquefaction. Most of the  
290 system was constructed of ductile iron pipe, which  
291 primarily failed by joint separation as seen in Figure  
292 9-11.



*Figure 9-11. Joint Separation in Ductile Iron Pipe due to Liquefaction during 1995 Kobe Earthquake (Courtesy of Kobe Water Department)*

293 High wind events, such as hurricanes or tornadoes,  
294 can result in damage to distribution lines, though not  
295 directly cause by high winds, but by uprooted trees.  
296 For example, during Hurricane Andrew, there was  
297 extensive damage to the water distribution systems  
298 in Southern Florida primarily caused by tree roots that had grown and wrapped themselves around the  
299 water mains and service lines. When these trees were uprooted by hurricane force winds, (Hurricane  
300 Andrew was a Category 5 on the Saffir-Sampson scale when it made landfall in Dade County, Florida)  
301 they pulled the lines too. Similar damage to water transmission and distribution systems occurred during  
302 Hurricanes Katrina and Rita in Louisiana (Allouche, 2006). As stated above, no matter the cause of  
303 damage, pipeline breaks resulting in a depressurized system contaminate the pipelines, affecting the  
304 potability of the water and requiring additional recovery time.

### 305 **9.2.2. Wastewater Systems**

306 Wastewater systems collect domestic and industrial liquid waste products and convey them to treatment  
307 plants through collection and conveyance systems and pump stations. After separation of solids,  
308 biological processing and disinfection, treated wastewater is discharged as effluent into a receiving body  
309 of water or alternatively, may be reused for irrigation or other purposes. Some utilities have separate  
310 collection systems for wastewater and storm water; other utilities have collection systems combine  
311 collected wastewater and storm water in the same pipelines.

312 Pipeline system failure can discharge raw sewage into basements, on to city streets, and into receiving  
313 waters, resulting in public health issues and environmental contamination. Standard wastewater systems

314 are composed of five general categories of infrastructure: 1) Collection, 2) Conveyance, 3) Pumping, 4)  
315 Treatment, and 5) Discharge. The basic function of each of these categories is briefly described in the  
316 following subsections. Apart from standard systems, pressure and vacuum systems are used on occasion.  
317 Pressure systems require a grinder pump at each house that pump the sewage through small diameter pipe  
318 to a larger pipe collector, and often times to a gravity sewer. Vacuum systems work in a similar manner,  
319 except a vacuum pump and tank pull sewage through shallow small diameter pipe to a central location.

#### 320 **9.2.2.1. Collection**

321 The collection pipeline network for wastewater systems is similar to that for water systems, except instead  
322 of delivering water to individual customers the wastewater collection system conveys liquid and other  
323 waste products away from customers. This is usually accomplished using gravity sewers. In some  
324 instances pumps convey wastewater through pressurized force mains. The elevation and grade of the  
325 pipelines in the system need to be carefully controlled to maintain gravity flow in the system. Infiltration  
326 and inflow of groundwater into the collection system through cracks and breaks in the pipe can  
327 significantly increase the volume of wastewater that arrives at the treatment plant. A variety of pipe  
328 materials are commonly found in collection systems, including:

- 329 • Vitrified clay – smaller diameter collection
- 330 • PVC – smaller diameter collection
- 331 • Asbestos cement – historically smaller diameter collection
- 332 • Reinforced concrete – larger diameter interceptors
- 333 • Steel – force mains or siphons
- 334 • Polyethylene – force mains or siphons
- 335 • Ductile iron (or historically cast iron) – collection or force mains
- 336 • Brick – larger capacity interceptors
- 337 • Fiberglass or FRP
- 338 • ABS

339 Gravity systems have manholes at regular intervals allowing access for cleaning and maintenance.  
340 Manholes are usually constructed with concrete, although historically manholes were often constructed  
341 with brick.

342 Wastewater collection pipes have similar causes of damage to those of water distribution and transmission  
343 pipelines. Wastewater collection pipelines can be exposed and damaged because of landslides, erosion, or  
344 scour, which damages or breaks the pipelines. Furthermore, wastewater collection pipelines can be  
345 damaged in high wind events by uprooted trees with root systems grown around the pipelines.

346 In the collection and conveyance system, pipelines are damaged by earthquake shaking, but more  
347 extensively due to liquefaction and associated lateral spreading. Sewer pipes can be damaged by shaking,  
348 which can cause joints to crack, but most remain operable. These cracks will ultimately have to be  
349 repaired to control infiltration. Liquefaction can result in pulled joints and displaced pipe. Another cause  
350 of failure is pipe flotation, occurring when a partially-filled gravity sewer is surrounded by liquefied soil.

351 Flooding can also damage wastewater collection pipelines in a number of ways. Pipelines that are co-  
352 located on bridges experience damage caused by flood inundation and flood-borne debris impact.  
353 Hydrodynamic forces associated with coastal flooding or high velocity flows are more likely to damage  
354 structures and attached pipelines than inundation alone. In the New Orleans area after Hurricane Katrina,  
355 the most common damage to buried wastewater pipelines observed by clean-up crews was separation of  
356 pipe joints, leaks, and breaks. This damage was believed to be the result of floodwaters supersaturating  
357 soils then draining, leading to soil shrinkage and subsidence. Without support of the soils, the rigid  
358 pipelines broke and fractured (Chisolm, 2012). Increased flow and pressurization of the wastewater

359 collection systems as the result of inflow and infiltration during flood events can also damage pipelines,  
360 particularly in cases where pipes are composed of materials such as vitrified clay. For example, during the  
361 1997 Red River Flood in Grand Forks, North Dakota, pressurization caused breaking of vitrified clay pipe  
362 and hairline cracks increased the rate of overall pipe deterioration (Chisolm 2012).

#### 363 **9.2.2.2. Conveyance**

364 The conveyance system for the wastewater network is similar to the transmission system in a water  
365 system. The conveyance pipelines are larger in diameter, and are often times deeper underground. In  
366 many instances, these conveyance systems were installed in the early to mid-1900s as the United States  
367 began to clean up its waterways. The conveyance systems are designed to collect sewage from the  
368 collection system and move it to the wastewater treatment plant. Like collection systems, it may include  
369 pump stations. Recently, the EPA is pushing wastewater utilities to minimize discharge of raw sewage to  
370 receive water runoff during heavy rain events. This often resulted in cities having sewers that carried both  
371 sewage and storm water. As a result, many conveyance systems now have a built-in large storage  
372 capacity, taking the form of a wide point in the line and, in some cases, simplified wastewater treatment  
373 facilities.

#### 374 **9.2.2.3. Pumping**

375 Gravity feed systems use pump or lift stations to lift wastewater to a higher elevation. The pump may  
376 discharge at the higher elevation to another section of gravity feed pipeline or may remain a pressurized  
377 force main and discharge at a distant location, such as a treatment plant. A pump station typically consists  
378 of a simple building that houses pumps, motors that power the pumps, pipes, and associated mechanical,  
379 electrical, and control equipment. The pumps can be located in a building (typically wetwell-drywell  
380 layout) or a large manhole (submersible). Pump stations are required to have standby generators to enable  
381 continued operation when the commercial power supply is interrupted.

382 Pump stations are vulnerable to a number of hazards, most notably earthquakes and flooding. Unless  
383 designed to be submersible, floodwater inundating pumps can disable and damage the pumps and their  
384 motors. This was a common cause of pump station failure in New York City during flood inundation  
385 from Hurricane Sandy (NYCDEP, 2013). Damage is even worse if salt water flooding is involved,  
386 leading to corrosion. Loss of commercial electrical power prevents operation of pumps if adequate  
387 standby power is not provided or these generators are not refueled in a timely manner. Earthquakes can  
388 cause liquefaction, resulting in buried wastewater collection wells at pump stations to float and tilt. This  
389 movement likely damages connecting piping and renders the pump station inoperable. Manholes and  
390 pump stations can float as well, when founded in liquefied soils, which changes the grade, making the  
391 sewer unusable or difficult to maintain.

#### 392 **9.2.2.4. Treatment**

393 Wastewater treatment plants process raw sewage from household and industrial sources so the resulting  
394 effluent discharge meets public health and environmental standards. The typical process is: 1)  
395 Pretreatment using screens and grit chambers, 2) Primary treatment in a sedimentation tank, 3) Secondary  
396 treatment using biological treatment and clarifiers, and 4) Disinfection using chlorine or other  
397 disinfectants. In some cases, the effluent is further treated at a higher level to be used for irrigation. Solids  
398 drawn off from the four processes are further treated in digesters and solidified using presses or  
399 centrifuges. These processes require an extensive mechanical and electrical equipment and piping.

400 Wastewater treatment plants are susceptible to damage from several natural hazards, particularly flooding.  
401 Wastewater treatment plants are often located in or near flood-prone areas because they return treated  
402 water to naturally occurring bodies of water via gravity. Therefore, they can be vulnerable to flood  
403 inundation or storm surge and wave action from coastal sources, causing damage and loss of functionality  
404 to buildings, equipment, and electrical and mechanical systems. The New York City Department of

## DISASTER RESILIENCE FRAMEWORK

75% Draft for San Diego CA Workshop

11 February, 2015

### Water and Wastewater Systems, Water and Wastewater Infrastructure

---

405 Environmental Protection (NYC DEP) noted in a recent study that all 14 of the wastewater treatment  
406 plants (WWTP) it owns and operates are at risk of flood damage (NYCDEP, 2013).

407 WWTPs in non-coastal regions of the United States are often located adjacent to rivers. With the  
408 projected sea level rise continuing through the 21<sup>st</sup> century, the frequency of these facilities flooding will  
409 increase. Some recent examples of WWTP riverine flooding include: 1) Nine days of lost functionality  
410 due to flooding of Valdosta, Georgia WWTP in 2009; 2) Flooding of the Pawtuxet River in Warwick,  
411 Rhode Island in 2010; and 3) Shut down of the Palmyra, Indiana WWTP in 2011 due to rising water  
412 levels.

413 In areas where wastewater treatment facilities are elevated or protected by levees, flooding can still lead  
414 to access issues. While the treatment facility itself may not be inundated, flooding around the facility can  
415 limit both ingress and egress of vital staff. This was the case for several WWTPs located along the  
416 Missouri and Mississippi Rivers during the 1993 flood. Access to facilities was only possible by boat,  
417 while roads inundated by the flood were not considered stable enough for larger vehicles, such as those  
418 that carried supplies for the plants (Sanders, 1997).

419 Release of untreated sewage is relatively common during major flood events when inflow and infiltration  
420 can overtax wastewater collection systems or when there are combined sewer overflows. During  
421 Hurricane Sandy, over 560 million gallons of untreated and diluted sewage, mixed with storm water and  
422 seawater, was released into waterways. This instance of sewage release was caused by infiltration of  
423 floodwaters into the sewer system, flood inundation of plant facilities, and power outages (NYC DEP,  
424 2013). After Hurricane Sandy, electronic controls were inundated and damaged in many wastewater  
425 treatment facilities, which significantly delayed the facilities' recovery times (FEMA 2013). Similarly,  
426 after Hurricane Rita in 2005, the City of Lake Charles had a citywide power loss that affected the  
427 wastewater treatment plant serving two-thirds of the city, releasing raw sewage into a nearby lake for over  
428 a week, until power was restored.

429 While discharge or raw sewage contaminates the receiving water, chemical contamination of sewage can  
430 impact the WWTP treatment process itself. For example, in the 1989 Loma Prieta earthquake in  
431 California, the East Bay Municipal Utility District (EBMUD) WWTP biological treatment process failed  
432 due to a spill in the collection system contaminating the treatment plant influent. Coupled with the spill,  
433 EBMUD lost power and were unable to pump oxygen into the treatment system, resulting in the  
434 secondary treatment system being inoperable for several weeks.

435 WWTPs are at a low point in the elevation of the system. Though flooding from different hazard events  
436 (hurricane storm surge, coastal and riverine flooding, and tsunamis) is a primary concern, earthquakes can  
437 damage facilities by shaking, permanent ground deformation, and liquefaction. Shaking is particularly  
438 problematic in process tanks and digesters where the hydraulic load from sloshing sewage impacts the  
439 tank walls. Liquefaction-induced permanent ground deformation often causes process tank joint  
440 separation, damage to pipelines, pipe racks, etc. Even if treatment structures are pile-supported, direct-  
441 buried piping can settle differentially and break. In the 2011 Christchurch earthquake in New Zealand,  
442 clarifiers settled differentially rendering them inoperable. In the 1995 Kobe Earthquake, the Higashinada  
443 WWTP site settled differentially as much as one meter, and moved laterally as much as two meters due to  
444 liquefaction heavily damaging non-pile-supported structures. The resulting damage is shown in Figure  
445 9-12. Figure 9-13 shows the Higashinada influent channel that was offset one meter by liquefaction  
446 during the 1995 Kobe earthquake.



*Figure 9-12. Non-Pile Supported Structures Failed Due to Liquefaction in 1995 Kobe Earthquake (Courtesy of Donald Ballantyne)*



*Figure 9-13. Higashinda WWTP Channel Offset by Liquefaction in 1995 Kobe Earthquake (Courtesy of Donald Ballantyne)*

447 Strong earthquakes can produce tsunamis that structurally damage treatment plant facilities due to lateral  
448 hydraulic loading and can inundate facilities, causing damage to electrical gear. The 2011 Tohoku  
449 earthquake in Japan caused heavy damage to the Sendai WWTP Effluent Pump Station's east wall, as  
450 shown in Figure 9-14. Much of the treatment plant's process tank equipment required replacement  
451 because of the large amount of damage, as shown in Figure 9-15.



*Figure 9-14. Sendai WWTP Effluent Pump Station Damaged by Tsunami in 2011 Tohoku Earthquake (Courtesy of Donald Ballantyne)*



*Figure 9-15. Sendai WWTP Equipment and Piping Damage from 2011 Earthquake (Courtesy of Donald Ballantyne)*

452 **9.2.2.5. Discharge**

453 Effluent from the treatment plant is discharged to a receiving body of water through an outfall. Outfalls  
454 are composed of a pipeline with a diffuser at the end discharging the water hundreds or thousands of feet  
455 away from the shoreline, at a depth that will minimize impact on the environment.

456 **9.3. Performance Goals**

457 The large and distributed nature of water and wastewater systems, combined with their interdependence  
458 on other infrastructure systems, limits the practicality of maintaining 100 percent operational capacity in  
459 the aftermath of a major natural disaster. This section provides an example of performance goals for water  
460 and wastewater systems in the fictional community of Centerville, USA.

461 Performance goals need to be discussed with individual utilities and communities before they are adopted.  
462 It is important to consider the uniqueness of the infrastructure of individual utilities and the specific needs  
463 of their customers when adopting system performance goals for a community. Water and wastewater  
464 stakeholder engagement is critical in establishing a community-specific level of service performance  
465 goals for each of the three different hazard levels (*routine*, *expected*, and *extreme*) defined in Chapter 3.  
466 Stakeholders should include representation from the following organizations as applicable:

- 467 • Residential customers
- 468 • Business owners
- 469 • Industry representatives
- 470 • Water wholesale customers
- 471 • Hospital representatives
- 472 • Fire department officials and crew
- 473 • Local government officials
- 474 • Local emergency management officials
- 475 • Drinking water regulators (Health Authority, etc.)
- 476 • Wastewater regulators (Dept. of Environmental Quality, Environmental Protection Agency, etc.)
- 477 • Water and wastewater utility operators and engineers
- 478 • Consulting engineers
- 479 • Interdependent infrastructure system operators (power, liquid fuel, transportation, etc.)

480 Establishing performance goals involves a discussion amongst the stakeholders about their expectations  
481 for the availability of water and wastewater systems following a hazard event in the short, intermediate,  
482 and long term phases for different hazard levels (e.g., *routine*, *expected*, and *extreme*). The assumed  
483 expectation of the public is that for *routine* hazard events there would be little, if any, interruption of  
484 service for water and wastewater lifelines. A dialogue is required between utilities and customers to  
485 determine the appropriate level of service performance goals for *expected* and *extreme* events. While  
486 examples are provided in Table 9-2 through Table 9-7 (pages 16 through 21), it is anticipated that actual  
487 goals will vary by community and are dependent on community priorities, as determined during the  
488 development of the goals and through outreach to and discussion among stakeholders.

489 There may be variability for an individual community's goals depending on the specific hazard being  
490 addressed. For example, if a community is subject to both seismic and wind hazards, they may determine  
491 that the damage to major collection lines within a wastewater system from an extreme seismic event is  
492 more likely and requires more restoration time, compared to damage from an extreme wind event.

493 There may be elements in a system that are so critical to public safety they need to be designed to remain  
494 operational after an *extreme* event. For example, failure of a water supply impoundment dam presents a  
495 significant life-safety hazard to downstream residents and should be designed for an *extreme* event.

496 Interdependencies of water and wastewater systems with other infrastructure also need to be considered  
497 when developing performance goals. For instance, availability of a reliable supply of liquid fuel impacts  
498 how long systems can run on standby generators and impacts repair crew's vehicles and equipment. In  
499 turn, delivery of liquid fuels depends on the status of the highway and bridge transportation network.

**DISASTER RESILIENCE FRAMEWORK**  
**75% Draft for San Diego CA Workshop**  
**11 February, 2015**  
**Water and Wastewater Systems, Performance Goals**

---

500 Performance goals are broken down into functional categories (i.e., water for fire suppression at key  
501 supply points, treatment plants operating to meet regulatory requirements, etc.) and further broken down  
502 into target timelines to restore the functional categories to 30 percent, 60 percent, and 90 percent  
503 operational status.

504 The infrastructure components in the example performance goals tables are not intended to be an  
505 exhaustive list. Some of the system components may not exist in all communities. For instance, in the  
506 water system performance goals, some communities may have the ability to distinguish between the  
507 general water supply and distribution and water supply for fire suppression. However, most systems are  
508 integrated and will not have a means to separate general supply and distribution from that needed for fire  
509 suppression. Additionally, some communities might have wholesale users – a system component listed in  
510 the performance goals – meaning their water system supplies all of the water used by other nearby,  
511 smaller communities. Wholesale users are treated as a critical part of the distribution system within the  
512 example, but are not a consideration for all communities. Each community will need to review these  
513 components to determine which ones to incorporate into their systems.

514 Similarly, communities may want to add certain system components to these goals that are not already  
515 captured here, to provide additional detail and allow for distinction between restoration timeframes. There  
516 may also be system components that are unique to a community that require special consideration. While  
517 the lists presented in the examples generally capture significant system components, it is recognized that  
518 communities may have additional infrastructure assets to consider.

519 The financial burden associated with upgrading all components of an entire system to be more disaster  
520 resilient would overwhelm the short-term capital improvement budgets of most utilities. Therefore,  
521 performance goals have been established around certain concepts.

- 522 • Prioritizing potential solutions to be implemented over many years to limit disruptions and  
523 recovery time rather than implementing them all at once
- 524 • Recognizing that there may be both short and long-term solutions capable of decreasing recovery  
525 times
- 526 • Balancing societal needs with realistic expectations of system performance

527 Focusing on major system components that form a backbone network capable of supplying key health and  
528 safety-related community needs shortly after a hazard event is one way to focus priorities. Recognizing  
529 that potentially less costly short-term solutions combined with longer term physical hardening of  
530 infrastructure allows for increased resilience would manage community's expectations and the cost of  
531 implementing solutions.

532

**DISASTER RESILIENCE FRAMEWORK**  
**75% Draft for San Diego CA Workshop**  
**11 February, 2015**  
**Water and Wastewater Systems, Performance Goals**

533 **Table 9-2. Example Water Infrastructure Performance Goals for Routine Event in Centerville, USA**

Disturbance			Restoration times		
(1)	Hazard	Any	(2)	30%	Restored
	Affected Area for Routine Event	Localized		60%	Restored
	Disruption Level	Minor		90%	Restored
			(3)	X	Current

534

Functional Category: Cluster	(4) Support Needed	(5) Target Goal	Overall Recovery Time for Hazard and Level Listed								
			Routine Hazard Level								
			Phase 1 – Short-Term			Phase 2 -- Intermediate			Phase 3 – Long-Term		
			Days			Wks			Mos		
			0	1	1-3	1-4	4-8	8-12	4	4-24	24+
<b>Source</b>		<b>1</b>									
Raw or source water and terminal reservoirs			90%		X						
Raw water conveyance (pump stations and piping to WTP)			90%		X						
Potable water at supply (WTP, wells, impoundment)			90%		X						
Water for fire suppression at key supply points (to promote redundancy)			90%		X						
<b>Transmission (including Booster Stations)</b>		<b>1</b>									
Backbone transmission facilities (pipelines, pump stations, and tanks)			90%		X						
<b>Control Systems</b>											
SCADA or other control systems			90%		X						
<b>Distribution</b>											
<b>Critical Facilities</b>		<b>1</b>									
Wholesale Users (other communities, rural water districts)			90%		X						
Hospitals, EOC, Police Station, Fire Stations			90%		X						
<b>Emergency Housing</b>		<b>1</b>									
Emergency Shelters			90%		X						
<b>Housing/Neighborhoods</b>		<b>2</b>									
Drink water available at community distribution centers				90%		X					
Water for fire suppression at fire hydrants				90%		X					
<b>Community Recovery Infrastructure</b>		<b>3</b>									
All other clusters					90%	X					

535 **Footnotes:**

- Specify hazard being considered  
Specify level -- Routine, Expected, Extreme  
Specify the size of the area affected - localized, community, regional  
Specify severity of disruption - minor, moderate, severe
- 30% 60% 90% Restoration times relate to number of elements of each cluster
- X Estimated restoration time for current conditions based on design standards and current inventory  
Relates to each cluster or category and represents the level of restoration of service to that cluster or category  
Listing for each category should represent the full range for the related clusters  
Category recovery times will be shown on the Summary Matrix  
"X" represents the recovery time anticipated to achieve a 90% recovery level for the current conditions
- Indicate levels of support anticipated by plan  
R Regional  
S State  
MS Multi-state  
C Civil Corporate Citizenship
- Indicate minimum performance category for all new construction.  
See Section 3.2.6

**DISASTER RESILIENCE FRAMEWORK**  
**75% Draft for San Diego CA Workshop**  
**11 February, 2015**  
**Water and Wastewater Systems, Performance Goals**

536 **Table 9-3: Example Water Infrastructure Performance Goals for Expected Event in Centerville, USA**

Disturbance			Restoration times		
(1)	Hazard	Any	(2)	30%	Restored
	Affected Area for Routine Event	Localized		60%	Restored
	Disruption Level	Minor		90%	Restored
			(3)	X	Current

537

Functional Category: Cluster	(4) Support Needed	(5) Target Goal	Overall Recovery Time for Hazard and Level Listed								
			Expected Hazard Level								
			Phase 1 – Short-Term			Phase 2 -- Intermediate			Phase 3 – Long-Term		
			Days			Wks			Mos		
			0	1	1-3	1-4	4-8	8-12	4	4-24	24+
<b>Source</b>		<b>1</b>									
Raw or source water and terminal reservoirs					90%						
Raw water conveyance (pump stations and piping to WTP)						90%			X		
Potable water at supply (WTP, wells, impoundment)			30%		60%	90%			X		
Water for fire suppression at key supply points (to promote redundancy)			90%			X					
<b>Transmission (including Booster Stations)</b>		<b>1</b>									
Backbone transmission facilities (pipelines, pump stations, and tanks)			90%					X			
<b>Control Systems</b>											
SCADA or other control systems			30%		60%	90%		X			
<b>Distribution</b>											
<b>Critical Facilities</b>		<b>1</b>									
Wholesale Users (other communities, rural water districts)				60%	90%						
Hospitals, EOC, Police Station, Fire Stations				60%	90%			X			
<b>Emergency Housing</b>		<b>1</b>									
Emergency Shelters				60%	90%			X			
<b>Housing/Neighborhoods</b>		<b>2</b>									
Drink water available at community distribution centers					60%	90%					
Water for fire suppression at fire hydrants						90%			X		
<b>Community Recovery Infrastructure</b>		<b>3</b>									
All other clusters					30%	90%			X		

538 **Footnotes:** See Table 9-2, page 16.

**DISASTER RESILIENCE FRAMEWORK**  
**75% Draft for San Diego CA Workshop**  
**11 February, 2015**  
**Water and Wastewater Systems, Performance Goals**

539 **Table 9-4: Example Water Infrastructure Performance Goals for Extreme Event in Centerville, USA**

Disturbance			Restoration times		
(1)	Hazard	Any	(2)	30%	Restored
	Affected Area for Extreme Event	Regional		60%	Restored
	Disruption Level	Severe		90%	Restored
			(3)	X	Current

540

Functional Category: Cluster	(4) Support Needed	(5) Target Goal	Overall Recovery Time for Hazard and Level Listed								
			Extreme Hazard Level								
			Phase 1 – Short-Term			Phase 2 – Intermediate			Phase 3 – Long-Term		
			Days			Wks			Mos		
			0	1	1-3	1-4	4-8	8-12	4	4-36	36+
<b>Source</b>		<b>1</b>									
Raw or source water and terminal reservoirs			30%		60%	90%			X		
Raw water conveyance (pump stations and piping to WTP)						60%	90%			X	
Potable water at supply (WTP, wells, impoundment)					30%	60%	90%			X	
Water for fire suppression at key supply points (to promote redundancy)					90%	X					
<b>Transmission (including Booster Stations)</b>		<b>1</b>									
Backbone transmission facilities (pipelines, pump stations, and tanks)			30%				60%		90%	X	
<b>Control Systems</b>											
SCADA or other control systems						30%	60%	90%			
<b>Distribution</b>											
<b>Critical Facilities</b>		<b>1</b>									
Wholesale Users (other communities, rural water districts)							60%		90%	X	
Hospitals, EOC, Police Station, Fire Stations						60%	90%		X		
<b>Emergency Housing</b>		<b>1</b>									
Emergency Shelters						60%	90%		X		
<b>Housing/Neighborhoods</b>		<b>2</b>									
Drink water available at community distribution centers					30%	60%	90%		X		
Water for fire suppression at fire hydrants						60%	90%			X	
<b>Community Recovery Infrastructure</b>		<b>3</b>									
All other clusters								60%	90%		X

541 **Footnotes:** See Table 9-2, page 16.

**DISASTER RESILIENCE FRAMEWORK**  
**75% Draft for San Diego CA Workshop**  
**11 February, 2015**  
**Water and Wastewater Systems, Performance Goals**

542 *Table 9-5. Example Wastewater Infrastructure Performance Goals for Routine Event in Centerville,*  
 543 *USA*

Disturbance			Restoration times		
(1)	Hazard	Any	(2)	30%	Restored
	Affected Area for Routine Event	Localized		60%	Restored
	Disruption Level	Minor		90%	Restored
			(3)	X	Current

544

Functional Category: Cluster	(4) Support Needed	(5) Target Goal	Overall Recovery Time for Hazard and Level Listed								
			Routine Hazard Level								
			Phase 1 – Short-Term			Phase 2 -- Intermediate			Phase 3 – Long-Term		
			Days			Wks			Mos		
			0	1	1-3	1-4	4-8	8-12	4	4-24	24+
<b>Treatment Plants</b>											
Treatment plants operating with primary treatment and disinfection					90%	X					
Treatment plants operating to meet regulatory requirements					90%	X					
<b>Trunk Lines</b>											
Backbone collection facilities (major trunkline, lift stations, siphons, relief mains, aerial crossings)				60%	90%	X					
Flow equalization basins				60%	90%	X					
<b>Control Systems</b>											
SCADA and other control systems			90%		X						
<b>Collection Lines</b>											
<b>Critical Facilities</b>											
Hospitals, EOC, Police Station, Fire Stations				90%	X						
<b>Emergency Housing</b>											
Emergency Shelters				90%	X						
<b>Housing/Neighborhoods</b>											
Threats to public health and safety controlled by containing & routing raw sewage away from public				60%	90%	X					
<b>Community Recovery Infrastructure</b>											
All other clusters				60%	90%	X					

545 **Footnotes:** See Table 9-2, page 16.

**DISASTER RESILIENCE FRAMEWORK**  
**75% Draft for San Diego CA Workshop**  
**11 February, 2015**  
**Water and Wastewater Systems, Performance Goals**

546  
547

*Table 9-6: Example Wastewater Infrastructure Performance Goals for Expected Event in Centerville, USA*

Disturbance			Restoration times		
(1)	Hazard	Any	(2)	30%	Restored
	Affected Area for Expected Event	Community		60%	Restored
	Disruption Level	Moderate		90%	Restored
			(3)	X	Current

548

Functional Category: Cluster	(4) Support Needed	(5) Target Goal	Overall Recovery Time for Hazard and Level Listed								
			Expected Hazard Level								
			Phase 1 – Short-Term			Phase 2 -- Intermediate			Phase 3 – Long-Term		
			Days			Wks			Mos		
			0	1	1-3	1-4	4-8	8-12	4	4-24	24+
<b>Treatment Plants</b>											
Treatment plants operating with primary treatment and disinfection					60%	90%					
Treatment plants operating to meet regulatory requirements				30%			60%	90%	X		
<b>Trunk Lines</b>											
Backbone collection facilities (major trunkline, lift stations, siphons, relief mains, aerial crossings)				30%		60%	90%			X	
Flow equalization basins				30%		60%	90%			X	
<b>Control Systems</b>											
SCADA and other control systems					30%		60%	90%		X	
<b>Collection Lines</b>											
<b>Critical Facilities</b>											
Hospitals, EOC, Police Station, Fire Stations				30%	90%				X		
<b>Emergency Housing</b>											
Emergency Shelters				30%	90%				X		
<b>Housing/Neighborhoods</b>											
Threats to public health and safety controlled by containing & routing raw sewage away from public				30%		60%	90%		X		
<b>Community Recovery Infrastructure</b>											
All other clusters					30%		60%		90%	X	

549

Footnotes: See Table 9-2, page 16.

**DISASTER RESILIENCE FRAMEWORK**  
**75% Draft for San Diego CA Workshop**  
**11 February, 2015**  
**Water and Wastewater Systems, Performance Goals**

550  
551

*Table 9-7: Example Wastewater Infrastructure Performance Goals for Extreme Event in Centerville, USA*

Disturbance			Restoration times		
(1)	Hazard	Any	(2)	30%	Restored
	Affected Area for Extreme Event	Regional		60%	Restored
	Disruption Level	Severe		90%	Restored
			(3)	X	Current

552

Functional Category: Cluster	(4) Support Needed	(5) Target Goal	Overall Recovery Time for Hazard and Level Listed								
			Extreme Hazard Level								
			Phase 1 – Short-Term			Phase 2 -- Intermediate			Phase 3 – Long-Term		
			Days			Wks			Mos		
			0	1	1-3	1-4	4-8	8-12	4	4-36	36+
<b>Treatment Plants</b>											
Treatment plants operating with primary treatment and disinfection						30%	60%		90%	X	
Treatment plants operating to meet regulatory requirements									90%		X
<b>Trunk Lines</b>											
Backbone collection facilities (major trunkline, lift stations, siphons, relief mains, aerial crossings)						30%	60%		90%		X
Flow equalization basins						30%	60%		90%		X
<b>Control Systems</b>											
SCADA and other control systems								60%		90%	X
<b>Collection Lines</b>											
<b>Critical Facilities</b>											
Hospitals, EOC, Police Station, Fire Stations						30%	90%			X	
<b>Emergency Housing</b>											
Emergency Shelters						30%	90%			X	
<b>Housing/Neighborhoods</b>											
Threats to public health and safety controlled by containing & routing raw sewage away from public						30%	60%	90%		X	
<b>Community Recovery Infrastructure</b>											
All other clusters								60%		90%	X

553 Footnotes: See Table 9-2, page 16.

554 **9.4. Regulatory Environment**

555 **9.4.1. Federal**

556 The federal EPA has requirements for drinking water quality defined in the Safe Drinking Water Act and  
557 wastewater discharge water quality defined in the Clean Water Act. These acts are amended on an  
558 ongoing basis. In most cases, the EPA gives states primacy to enforce these requirements. There are  
559 certain prescriptive requirements associated with each.

560 *SDWA Example Requirements*

- 561 • Filtration of surface water supplies, except in some cases special treatment of particularly clean
- 562 surface water supplies
- 563 • Disinfection of supplies (except a few groundwater supplies)
- 564 • Covering of treated water storage

565 *Clean Water Act Example Requirements*

- 566 • Secondary treatment of wastewater discharges
- 567 • Disinfection of wastewater discharges

568 In general, these regulations all focus on water quality and have limited interest in catastrophic hazard  
569 event impacts and planning.

570 **9.4.2. State**

571 *State Drinking Water Programs.* States typically regulate water quality and require treatment approaches  
572 for recycled water. States ensure water systems meet Safe Drinking Water Act standards by ensuring  
573 water systems test for contaminants, reviewing plans for water system improvements, conducting on-site  
574 inspections and sanitary surveys, providing training and technical assistance, and taking action against  
575 non-compliant water systems.

576 *State Water Quality Programs.* States also ensure water systems meet Clean Water Act water quality  
577 standards using state water quality programs. They develop and implement water quality standards,  
578 regulate sewage treatment systems and industrial dischargers, collect and evaluate water quality data,  
579 provide training and technical assistance, and take action against non-compliant wastewater systems.

580 *Emergency Planning and Community Right-to-Know Act (EPCRA).* Facilities that store, use, or release  
581 certain chemicals may be subject to reporting requirements to state and/or local agencies through EPCRA.  
582 Information in reports then becomes publically available. Treatment chemicals stored and used at water  
583 treatment plants often require this type of reporting.

584 *Planning Requirements.* Water and wastewater planning and design requirements are generally  
585 controlled by states and local governments. States typically require comprehensive plans for water and  
586 wastewater system are prepared on a regular basis to assess future system needs (e.g. capacity) and how  
587 those needs will be met. The elements of those comprehensive plans are defined by the state. Often times,  
588 these plans include requirements to identify hazards to which the system could be subjected, and how the  
589 utility will address those hazards. These are typically quite general in nature and do not include detailed  
590 design criteria.

591 **9.4.3. Local**

592 Individual municipalities or utility districts may elect to impose regulatory standards in excess of federal  
593 and state standards. In practice, this is seldom done due to the increased cost to customers associated with  
594 meeting higher-than-minimum regulatory standards.

595 **9.5. Standards and Codes**

596 The state and local government are responsible for adopting model building codes, such as the  
597 International Building Code (IBC). Model building codes rely heavily on standards, such ASCE-7,  
598 *Minimum Design Loads for Buildings and Other Structures*. In many cases, the state will adopt these  
599 model codes; in some cases, local jurisdictions modify them to suit their needs. The IBC and ASCE-7  
600 focus on building structure life safety. State and local agencies will also have special requirements for  
601 high risk facilities, such as dams. The Federal Energy Regulatory Commission controls designs of  
602 hydroelectric generating dams.

603 The development of design codes is a long and arduous process. These codes are updated on a regular  
604 basis taking into account performance of facilities since the last code was issued and other developments  
605 in the building industry. Once they are finalized, they are voted on by the code committee and finally  
606 adopted by state and/or local jurisdictions. Once a code is well vetted, the state and local jurisdictions  
607 adopt it.

608 The following subsections discuss some of the codes, standards, and guidelines that are important to the  
609 disaster resilience of water and wastewater infrastructure, the anticipated performance of the  
610 infrastructure after an expected hazard event, and the long-term recovery levels of the infrastructure when  
611 damage does occur.

612 **9.5.1. New Construction**

613 *Design Standards*. Developed and adopted by various organizations, the two organizations that have  
614 standards most relevant to natural hazard impacts on the water and wastewater industry include:

- 615 • **American Concrete Institute** – standards addressing concrete process tanks (ACI 350)
- 616 • **American Water Works Association (AWWA)** –
  - 617 ▪ Standards addressing design of water storage tanks (AWWA D100, D110, D115), addressing
  - 618 seismic design of water storage tanks
  - 619 ▪ Standard AWWA-J100, Risk and Resilience Management of Water and Wastewater Systems,
  - 620 addressing performance of water and wastewater systems when subjected to natural and
  - 621 manmade hazards

622 AWWA has other standards addressing pipeline design and water quality. However, none of these other  
623 standards addresses seismic design for other natural hazards.

624 For the design of new underground pipelines, there is not a unifying code for water and wastewater  
625 systems. This is especially true for seismic design of buried water and wastewater pipelines or buried  
626 pipelines that may be impacted by landslides induced by flooding. Often the Chief Engineer of a  
627 particular utility is responsible for establishing its design practices. While these agency-specific design  
628 practices are generally based on industry recommendations, variability in standards used by utilities  
629 results in variability in the intended system reliability for natural and man-made hazards.

630 Some utilities develop their own standards to address significant local hazards specifically. For example,  
631 the San Francisco Public Utilities Commission (SFPUC) developed its own internal standard that outlines  
632 level of service performance goals following a major Bay Area earthquake and specific requirements for  
633 design and retrofit of aboveground and underground infrastructure. The SFPUC Engineering Standard  
634 *General Seismic Requirements for Design of New Facilities and Upgrade of Existing Facilities* (SFPUC,  
635 2006) establishes design criteria that in many cases are more stringent than building codes and/or industry  
636 standards, yet ensures the SFPUC achieves its basic level of service performance goal to deliver winter  
637 day demand to their wholesale customers within 24 hours after a major earthquake.

638 *Guidelines and Manuals of Practice*. A number of organizations have developed guidelines intended for  
639 use by the industry to enhance design of the particular product being addressed. Table 9-8 lists some of  
640 the model codes, standards, and guidance documents applicable to water and wastewater infrastructure.

**DISASTER RESILIENCE FRAMEWORK**  
**75% Draft for San Diego CA Workshop**  
**11 February, 2015**  
**Water and Wastewater Systems, Standards and Codes**

641 This table also shows a matrix of system component to document. This list is not intended to be  
642 exhaustive. However, the reader should be aware of these documents that pertain to disaster resilience.

643 **Table 9-8. Codes, Standards, and Guidelines for Hazard Resistance of Water and Wastewater Facilities**

Org	Category (1)	Name	General	Pipelines	Pumping	Storage	Treatment
IBC	C	2012 International Building Code or applicable jurisdictional building code	x				
ASCE	S	Minimum Design Loads for Buildings and Other Structures	x				
ACI	S	350 Code Requirements for Environmental Engineering Concrete Structures				x	x
ACI	S	371R-08 Guide for the Analysis, Design, and Construction of Elevated Concrete and Composite Steel-Concrete Water Storage Tanks				x	
ACI	S	372R-03 Design and Construction of Circular Wire- and Strand-Wrapped Prestressed Concrete Structures				x	x
AWWA	S	D100-11 Welded Carbon Steel Tanks for Water Storage				x	
AWWA	S	D110-13 Wire- and Strand-Wound, Circular, Prestressed Concrete Tanks				x	
AWWA	S	D115-06 Tendon-Prestressed Concrete Water Tanks				x	
AWWA	S	G430-14 Security Practices for Operation and Management	x				
AWWA	S	J100-10 Risk Analysis and Management for Critical Asset Protection Standard for Risk and Resilience Management of Water and Wastewater Systems	x				
AWWA	S	G440-11 Emergency Preparedness Practices	x				
ALA	G	Guidelines for Implementing Performance Assessments of Water Systems	x				
ALA	G	Guidelines for the Design of Buried Steel Pipe (2001)		x			
ALA	G	Seismic Design and Retrofit of Piping Systems (2002)			x		x
ALA	G	Seismic Fragility Formulations for Water Systems (2001)	x				
ALA	G	Seismic Guidelines for Water Pipelines (2005)		x			
ALA	G	Wastewater System Performance Assessment Guideline (2004)	x				
ASCE	G	Guidelines for Seismic Design of Oil and Gas Pipeline Systems (1984)		x			
AWWA	G	Emergency Power Source Planning for Water and Wastewater	x				
AWWA	G	M9 Concrete Pressure Pipe		x			
AWWA	G	M11 Steel Pipe: A Guide for Design and Installation		x			
AWWA	G	M19 Emergency Planning for Water Utilities	x				
AWWA	G	M60 Drought Preparedness and Response	x				
AWWA	G	Minimizing Earthquake Damage, A Guide for Water Utilities (1994)	x				
EPA/AWWA	G	Planning for an Emergency Drinking Water Supply	x				
MCEER	G	MCEER-08-0009 Fragility Analysis of Water Supply Systems (2008)	x				
MCEER	G	Monograph Series No. 3 Response of Buried Pipelines Subject to Earthquakes		x			
MCEER	G	Monograph Series No. 4 Seismic Design of Buried and Offshore Pipelines		x			
TCLEE	G	Monograph 15 Guidelines for the Seismic Evaluation and Upgrade of Water Transmission Facilities (1999)		x			
TCLEE	G	Monograph 22 Seismic Screening Checklists for Water and Wastewater Facilities (2002)	x				
WEF	G	Emergency Planning, Response, and Recovery	x				
WEF	G	Guide for Municipal Wet Weather Strategies	x				
WEF	G	MOP 28 Upgrading and Retrofitting Water and Wastewater Treatment Plants					x
WEF	G	MOP 8 Design of Municipal Wastewater Treatment Plants					x
WEF	G	MOP FD-17 Prevention and Control of Sewer System Overflows	x				

644 C – Code; S – Standard; G – Guideline or Manual of Practice (MOP)

645 **9.5.1.1. Implied or Stated Performance Levels for Expected Hazard Levels**

646 Design of new aboveground structures (i.e., treatment plant office and lab buildings, pump stations,  
647 process tanks, water storage tanks and reservoirs, etc.) is typically governed by local building codes or  
648 design standards that prescribe a similar wind, seismic, or other hazard as the local building code. Design

**DISASTER RESILIENCE FRAMEWORK**

**75% Draft for San Diego CA Workshop**

**11 February, 2015**

**Water and Wastewater Systems, Standards and Codes**

649 loads are prescribed by a consensus-based standard, *Minimum Design Loads for Buildings and Other*  
 650 *Structures* (ASCE, 2010). This standard uses the concept of Risk Category to increase the design force  
 651 level for important structures. Typical buildings are assigned to Risk Category II. Water and wastewater  
 652 treatment facilities are assigned to Risk Category III, because failure of these facilities can cause  
 653 disruption to civilian life and potentially cause public health risks. Water storage facilities and pump  
 654 stations required to maintain water pressure for fire suppression are assigned to the highest category, Risk  
 655 Category IV.

656 The building code intends that structures designed as Risk Category III or IV should remain operational  
 657 or require only minor repairs to be put back into operation following a design level (*expected*) wind,  
 658 seismic, or other event. By designing for this performance target for the *expected* level event, water and  
 659 wastewater systems should remain operational under a *routine* level event and may experience moderate  
 660 to major damage during an *extreme* level event.

661 The performance level implied by codes and standards for new construction provides an indication of the  
 662 recovery level (timeframe) expected for individual system components. The timeframe required for water  
 663 or wastewater systems to return to normal operating status following a hazard event is highly dependent  
 664 on the recovery time for individual system components and the system’s specific characteristics (e.g.,  
 665 type and number of components, age of construction, system redundancy, etc.). Estimating system  
 666 recovery times for a specific hazard requires in-depth engineering and operational knowledge of the  
 667 system.

668 Table 9-9 summarizes water and wastewater system component performance and recovery levels for  
 669 earthquake hazard levels as implied by current codes and standards for new construction. Predicted  
 670 recovery times are based on individual system components.

671 ***Table 9-9. Water and Wastewater System Component Performance and Recovery Levels for Various***  
 672 ***Earthquake Hazard Levels as Implied by Current Codes and Standards for New Construction***

System Component	Hazard Level	Performance Level	Recovery Level
Structures (pump stations, treatment plants, office/lab buildings, tanks, reservoirs, etc.)	Routine (50 year return period earthquake)	Safe and operational	Resume 100% service within days
	Expected (500 year return period earthquake)	Risk Category III (I=1.25) – Safe and usable during repair	Resume 100% service within months
		Risk Category IV (I=1.5) – Safe and operational	Resume 100% service within days
	Extreme (2500 year return period earthquake)	Risk Category III (I=1.25) – Safe and not usable	Resume 100% service within years
		Risk Category IV (I=1.5) – Safe and usable during repair or not usable	Resume 100% service within months to years
	Nonstructural components (process, lab, mechanical, electrical, and plumbing equipment, etc.)	Routine (50 year return period earthquake)	Safe and operational
Expected (500 year return period earthquake)		Risk Category III (I=1.25) – Safe and usable during repair	Resume 100% service within months
		Risk Category IV (I=1.5) – Safe and operational	Resume 100% service within days
Extreme (2500 year return period earthquake)		Risk Category III (I=1.25) – Safe and not usable	Resume 100% service within years
		Risk Category IV (I=1.5) – Safe and usable during repair or not usable	Resume 100% service within months to years
Pipelines		Routine (50 year return period earthquake)	Operational
	Expected (500 year return period earthquake)	Operational to not usable	Resume 100% service within months
	Extreme (2500 year return period earthquake)	Not usable	Resume 100% service within years

673 **9.5.2. Existing Construction**

674 **9.5.2.1. Implied or Stated Performance Levels for Expected Hazard Levels**

675 The design seismic hazard level was refined over time as the engineering and seismology community's  
676 understanding of United States seismicity improved. A significant portion of water and wastewater  
677 system components in the high seismicity regions of the western and central United States were designed  
678 and constructed considering a significantly lower seismic hazard than the hazard used by current codes  
679 and standards.

680 Expected seismic performance of water and wastewater system components is dependent on the hazard  
681 level, codes and standards used in original design, and the type of structure. System components built  
682 prior to the mid-1970s are generally expected to perform poorly in earthquakes, because design codes and  
683 standards used at that time lacked the detailed requirements that reflect our current understanding of  
684 structures' behaviors during earthquakes. System components built after the early 2000s are generally  
685 expected to perform similar to new construction as described above. Performance of system components  
686 built between the mid-1970s and early 2000s is dependent on the code edition and seismic hazard used in  
687 design. Structures that satisfy the benchmark building criteria of ASCE 41-13 (ASCE, 2013) and are in  
688 areas that haven't experienced a significant increase in seismicity are generally expected to perform  
689 similar to new construction as described above. However, some types of structures are inherently rugged.  
690 For example, many older cast-in-place concrete structures, particularly single story buildings with few  
691 opening would be expected to perform well.

692 Anticipated performance of nonstructural components should be evaluated on a case-by-case basis, as  
693 engineers now pay closer attention to seismic design and construction of nonstructural components.

694 Anticipated performance of pipelines should be evaluated on a system-by-system basis because  
695 performance of pipelines is dependent on pipe type, joint type, and earthquake ground movement  
696 parameters. Even today, there is no code or standard for seismic design of pipelines.

697 **9.5.2.2. Recovery Levels**

698 In the past, infrastructure systems have not performed to the level that communities would desire with  
699 extended recovery times beyond the example performance goals in Section 9.3. There are a number of  
700 examples of disaster events that have rendered utilities non-functional for weeks following the event and  
701 illustrate importance of considering the interdependencies of water and wastewater systems with other  
702 systems of the built environment. A few notable events and their actual recover levels are discussed  
703 herein.

704 ***Great Flood of 1993.*** In the Great Flood of 1993, the Raccoon River overtopped its banks and submerged  
705 the Des Moines, Iowa WWTP. The water receded and the plant was able to restore non-potable water  
706 within 12 days and potable water within 19 days. The water outage disrupted restaurant and hotel  
707 operations. The Principal Insurance Company headquarters had to haul in water and pump it into the  
708 building to cool computers. AT&T's regional central office came within minutes of losing phone service  
709 because of computer cooling issues.

710 ***Northridge and Kobe Earthquakes.*** In the 1994 Northridge earthquake, the Los Angeles Department of  
711 Water and Power's distribution system suffered approximately 1,000 pipeline failures, primarily in the  
712 San Fernando Valley. With their own forces and mutual aid, they were able to fully restore potable water  
713 service to everyone within 12 days. A year later, the 1995 Kobe Japan earthquake suffered 1,200 pipeline  
714 failures resulting in lost service to all households for up to 60 days.

715 ***Christchurch, New Zealand and Tohoku, Japan Earthquakes.*** The recent 2011 Christchurch New  
716 Zealand, and Tohoku Japan earthquakes both resulted in outages lasting in excess of 40 days. Impacted  
717 Japanese cities were assisted by mutual aid from their colleagues from cities in western Japan.

**9.6. Strategies for Implementing Community Resilience Plans**

718 Section 9.2 discusses components of water and wastewater infrastructure system. The discussion includes  
719 examples from different types of hazards to encourage the reader to think about the different hazards that  
720 could impact the communication and information infrastructure in their community. The number, types,  
721 and magnitudes of hazards that need to be considered will vary from community to community.  
722

723 Section 9.3 discusses example performance goals for the water and wastewater infrastructure system in  
724 fictional town Centerville, USA. These example performance goals are provided for the routine, expected  
725 and extreme event. However, the performance goals should be adjusted by the community based on its  
726 social needs.

727 Section 9.4 and 9.5 outline some of the regulatory levels and issues, and codes and standards that the  
728 reader should keep in mind when planning to make upgrades/changes to existing infrastructure as well as  
729 building new structures for their water and wastewater infrastructure system. The objective of this section  
730 is use the information from Sections 9.2 through 9.5 to provide guidance on how a community should  
731 work through the process of assessing their communications infrastructure, defining strategies to make its  
732 infrastructure more resilient, and narrowing the resilience gaps.

**9.6.1. Available Guidance**

734 The purpose of the assessment is to quantify the anticipated performance and recovery of the overall  
735 system to determine whether it meets the performance goals described in Section 9.3. If the system does  
736 not meet the objectives, the assessment should identify system facility and pipe deficiencies that should  
737 be improved to achieve those performance goals.

738 Section 9.2.1 describes the basic components of water and wastewater systems and observations of where  
739 these systems failed in past disasters. System performance is also highly dependent on the current  
740 condition of the system and standards used in its design. Information about past disaster performance of  
741 similar systems combined with knowledge of current condition and original design standards of the  
742 system help a utility estimate the expected level of service they could provide after a hazard event. There  
743 is likely a gap in the level of service a system would provide if a hazard event occurred today versus  
744 community-established performance goals. It is likely that the capital expenditure required to close this  
745 performance gap far exceeds the short-term capital improvement project budgets of the utility. However,  
746 the resilience of any system can be improved incrementally over time by appropriately considering design  
747 criteria to reduce the impact of natural and man-made hazards in designing new and upgrading existing  
748 infrastructure. To estimate the level of service a water or wastewater system would provide after a given  
749 scenario hazard event, an assessment of expected damage to the system and restoration times is required.

750 The level of detail of this assessment can take one of three basic forms.

- 751 • **Tier 1** – A high-level assessment of hazards and their performance conducted by persons  
752 knowledgeable about the system (chief engineer, operations manager, etc.). This can be  
753 accomplished in a workshop setting using system maps and schematics, along with hazard maps  
754 of the service area, such as liquefaction susceptibility or flood plain maps. Restoration times will  
755 be based on professional judgment of the workshop participants.
- 756 • **Tier 2** – A more refined assessment based on published scenario events and hazard zones, system  
757 inventory (i.e., facility type, age, condition, and location relative to hazards, and pipe type, length  
758 and soil type), site visits, and use of generalized component fragilities, such as those included in  
759 HAZUS-MH and ALA documents. Restoration times are based on the extent of damage (e.g.,  
760 number of pipeline breaks), estimates of the time to repair each category of damage, and crews  
761 and equipment available for restoration.
- 762 • **Tier 3** – A detailed assessment of all components in a system, specific component fragilities, and  
763 the interdependencies of system components. Same as Tier 2, with the addition of detailed

## DISASTER RESILIENCE FRAMEWORK

75% Draft for San Diego CA Workshop

11 February, 2015

### Water and Wastewater Systems, Strategies for Implementing Community Resilience Plans

---

764 analysis (e.g. geotechnical, structural or hydraulic) of facilities and pipelines determined to be  
765 vulnerable and critical, should they fail, significantly impacting the overall system operation.

766 To characterize the current disaster resilience of water and wastewater systems appropriately, each service  
767 provider should undergo a Tier 1 assessment. If potential resilience vulnerabilities are identified, they  
768 should undergo a more refined Tier 2 or 3 assessment. Several methodologies and tools are available to  
769 conduct these resilience assessments, a few of which are described below.

770 HAZUS-MH is a multi-hazard (flood, earthquake, and hurricane) loss estimation tool developed by the  
771 Federal Emergency Management Agency (FEMA) for use in pre-disaster mitigation, emergency  
772 preparedness, and response and recovery planning (FEMA, 2012). Communities can use this tool to  
773 characterize their hazard exposure, estimate losses to the water and wastewater systems, and estimate  
774 repair costs and duration. It assists in conducting a Tier 2 analysis and an AWWA J100 analysis as  
775 discussed below.

776 The ANSI/AWWA J100-10 *Standard for Risk and Resilience Management of Water and Wastewater*  
777 *Systems* (AWWA, 2010) provides a methodology for conducting multi-hazard system risk and resilience  
778 assessments. The J100 aligns the national homeland security objectives in HSPD-5, PPD-8, PPD-21 and  
779 EO 13636. The J100 standard consists of a seven-step process for analyzing and supporting management  
780 decisions that maximize risk reduction and/or enhance resilience at the utility and the community it  
781 serves.

- 782 1. Asset Characterization
- 783 2. Threat Characterization
- 784 3. Consequence Analysis
- 785 4. Vulnerability Analysis
- 786 5. Threat Analysis
- 787 6. Risk/Resilience Analysis
- 788 7. Risk/Resilience Management

789 Asset level resilience for specific threats is part of the J100 assessment methodology, which may support  
790 a community's process for determining current performance and target performance (Section 9.3). The  
791 J100 also includes the Utility Resilience Index (URI), which is a system-level assessment of operational  
792 and financial indicators that are essential to resilience and, therefore, an asset's ability to effectively serve  
793 a community. The URI serves as a benchmark to evaluate potential resilience improvement projects and  
794 as a measure to track a utility's progress over time towards achieving resilience performance goals.

795 Several tools were developed by the U.S. Environmental Protection Agency to support the water utility  
796 assessment of risks. The Vulnerability Self-Assessment Tool (VSAT) (EPA 2014) is designed to assist  
797 water and wastewater utilities' application of the J100 standard. VSAT is complemented by the Water  
798 Health and Economic Analysis Tool (WHEAT), which quantifies three aspects of consequence associated  
799 with an adverse event's 1) public health impact, 2) utility-level financial impact, and 3) direct and indirect  
800 regional economic impact (EPA, 2014). WHEAT is specifically aligned with step 3 (consequence  
801 analysis) of J100 standard.

802 The EPA's National Homeland Security Research Center (NHSRC) also supported efforts to enhance  
803 utility resilience. Collaboration with AWWA resulted in the development of *Planning for an Emergency*  
804 *Drinking Water Supply*, which directly supports a capability assessment based on worst reasonable threats  
805 in J100 to determine options for maintaining service.

806 An example Tier 2 resilience assessment procedure for water systems is outlined in the following.

#### 807 **9.6.1.1. Example Tier 2 Resilience Assessment for Earthquake:**

- 808 1. Identify the appropriate earthquake scenario or scenarios. Develop or obtain ground motion  
809 information for each. The USGS has scenarios available for a suite of earthquakes in the U.S.

## DISASTER RESILIENCE FRAMEWORK

75% Draft for San Diego CA Workshop

11 February, 2015

### Water and Wastewater Systems, Strategies for Implementing Community Resilience Plans

---

810 Obtain liquefaction and landslide hazard maps available from the state department of geology.  
811 Use GIS for all mapping.

#### 812 *For buried pipelines:*

- 813 2. Compile an inventory of system pipelines including pipe material, joint type, and length.
- 814 3. In GIS, superimpose the pipeline distribution system onto maps of the scenario hazard (peak  
815 ground velocity, liquefaction potential, and landslide potential).
- 816 4. Use empirical relationships developed by the American Lifelines Alliance (ALA) to predict the  
817 number of breaks and leaks in the pipeline system.
- 818 5. Estimate the time required to repair the predicted number of breaks and leaks based on historical  
819 crew productivity data. Modify this repair time, as appropriate, based on discussions of the  
820 expected damage states of interdependent lifelines (transportation, liquid fuel, etc.).

#### 821 *For aboveground infrastructure:*

- 822 6. Compile an inventory of system components (tanks, pump stations, treatment plants, etc.),  
823 including type of construction, date of original construction, and any subsequent retrofits.
- 824 7. Estimate the level of damage predicted for the aboveground water system components based on  
825 observations from past earthquakes, the seismic hazard prescribed by the building code at the  
826 time of original construction or retrofit, and the professional judgment of engineers  
827 knowledgeable in the seismic performance of water systems. Use fragility curves found in  
828 HAZUS-MH to determine the anticipated performance for a particular facility type for a given  
829 ground motion.
- 830 8. Estimate the time required to repair the predicted damage to aboveground infrastructure. Modify  
831 this repair time, as appropriate, based on discussions of the expected damage states of  
832 interdependent lifelines (transportation, liquid fuel, etc.)

#### 833 *For the system:*

- 834 9. Determine the expected system performance based on the damage to pipelines and facilities in a  
835 workshop format.
- 836 10. Determine the expected repair time for the system based on the repair times for buried pipelines  
837 and aboveground infrastructure estimated in steps 5 and 8.
- 838 11. Compare this estimate of repair time for the system to the performance goals established by the  
839 community to determine the resilience gap.

840 These different resilience assessment approaches should be evaluated and refined into one consistent  
841 methodology prior to implementation of nationwide water and wastewater system resilience assessments.  
842 The tier level of the assessment increases by conducting detailed analyses of each facility and pipeline.

843 Note that recovery time for utilities that purchase water from wholesale suppliers is highly dependent on  
844 the recovery time of the supplying utility. Wholesale water suppliers should work with their customers to  
845 assess the expected damage and restorations times from the source to the final individual customers. In  
846 this case, water and wastewater system resilience assessments may require a regional approach to  
847 characterize the anticipated performance of the system of systems in a hazard event appropriately.

#### 848 **9.6.2. Strategies for New Construction**

849 Water and wastewater providers should consider resilience performance goals in all new construction  
850 projects. Projects should be designed to satisfy or exceed code requirements, where code minimum  
851 standards are not anticipated to provide a final product that would be expected to meet the utility's  
852 resilience performance goals. If no codes exist for a particular category of structure or facility, the  
853 designer should investigate guidelines that address hazard-resistant design issues (see Table 9.4). The  
854 incremental cost of designing and constructing for improved disaster resilience may be a relatively small  
855 percentage of total project costs.

856 **9.6.3. Strategies for Existing Construction**

857 Water and wastewater providers should consider resilience improvements to existing infrastructure as part  
858 of the capital improvement planning process. The process of conducting system resilience assessments  
859 will likely identify key pipelines and facilities that significantly impact the overall resilience of a system.  
860 These components should be evaluated in detail. Providers should evaluate a number of potential  
861 strategies, including retrofit or replacement of existing components, or building redundant components in  
862 anticipation of failure of existing components. Retrofit of existing infrastructure or new redundant  
863 components should be designed such that the final product would be expected to meet the utility's  
864 resilience performance goals. In some cases, redundant systems can be justified based on increasing  
865 demand requirements. The "new" redundant system could provide on its own an adequate supply to meet  
866 an average day's demand until the damaged system was repaired. Whatever is done needs to be part of the  
867 day-to-day needs of the utility. That is, if special features added to a system to increase resilience are  
868 never used, there is a high likelihood they will not be functional when they are needed.

869 Once water and wastewater providers and the community establish resilience performance goals and  
870 complete baseline resilience assessments, there may be a number of goals not currently met due to the  
871 anticipated performance of system components, financial resources of the utility, interdependencies with  
872 other lifelines, etc. These performance gaps are likely to be addressed by a phased program (perhaps over  
873 as long as a 50-year period) of new construction, retrofit of existing system components to better  
874 withstand hazard events, modifications to emergency response plans, coordination with interdependent  
875 lifeline providers, and other strategies. It is expected that these resilience enhancements will be coupled  
876 with other system improvements to maximize the benefit of limited financial resources.

877 For instance, it can be difficult to justify replacing hundreds of miles of water pipelines based on  
878 earthquake resilience considerations alone, but coupled with replacement of aging and failing pipelines,  
879 the incremental cost of using more earthquake-resistant pipe materials and joints is relatively minor.  
880 Major resilience improvements that take place on a shorter timeline require a more extensive campaign of  
881 public outreach and education.

882 **9.7. References**

883 Allouche, E.N., Sterline, R.L., Chisolm, E., Hill, D., and Hall, D. (2006). Assessment of Damage to  
884 Urban Buried Infrastructure in the Aftermath of Hurricanes Katrina and Rita. *Proceedings*  
885 *Pipelines 2006: Service to the Owner*. ASCE.

886 ASCE (2013). *Seismic Evaluation and Rehabilitation of Existing Buildings*. Reston, VA: American  
887 Society of Civil Engineers.

888 Aubuchon, C.P., & Morley, Kevin (2012). *The Economic Value of Water: Providing Confidence and*  
889 *Context to FEMA's Methodology*. *Journal of Homeland Security and Emergency Management*,  
890 10(1), 2194-6361.

891 AWWA (1994). *Minimizing Earthquake Damage, A Guide for Water Utilities*. Denver, CO: American  
892 Water Works Association.

893 AWWA (2001). *M19 Emergency Planning for Water Utilities*. Denver, CO: American Water Works  
894 Association.

895 AWWA (2004). *Emergency Power Source Planning for Water and Wastewater*. Denver, CO: American  
896 Water Works Association.

897 AWWA (2010). *ANSI/AWWA J100-10 Risk and Resilience Management of Water and Wastewater*  
898 *Systems*. Denver, CO: American Water Works Association.

899 AWWA (2011). *ANSI/AWWA G440-11 Emergency Preparedness Practices*. Denver, CO: American  
900 Water Works Association.

**DISASTER RESILIENCE FRAMEWORK**  
**75% Draft for San Diego CA Workshop**  
**11 February, 2015**  
**Water and Wastewater Systems, References**

---

- 901 AWWA (2014). *ANSI/AWWA G430-14 Security Practices for Operation and Management*. Denver, CO:  
902 American Water Works Association.
- 903 Ballantyne, D., & Crouse, C. (1997). *Reliability and Restoration of Water Supply Systems for Fire*  
904 *Suppression and Drinking Following Earthquakes*. Gaithersburg, MD: National Institute of  
905 Standards and Technology.
- 906 Chisolm, E. & Matthews, J. (2012). *Impact of Hurricanes and Flooding on Buried Infrastructure*.  
907 *Leadership and Management in Engineering*. July 2012. Vol. 12, Issue 3.
- 908 Eiding, J. (2012). *Performance of Water Systems during the Maule Mw 8.8 Earthquake 27 February*  
909 *2010. Earthquake Spectra*, Vol. 28, No. S1, S605-S620.
- 910 Eiding, J., & Tang, A. (2014). *Christchurch, New Zealand Earthquake Sequence of Mw 7.1 September*  
911 *04, 2010 Mw 6.3 February 22, 2011 Mw 6.0 June 13, 2011: Lifeline Performance*. Reston, VA:  
912 American Society of Civil Engineers.
- 913 Elliott, T., & Tang, A. (2009). *Pacific Northwest Storms of December 1-4, 2007 Lifeline Performance*.  
914 Reston, VA: American Society of Civil Engineers.
- 915 EPA (2010). *VSAT – Risk Assessment Tool for Water Sector Utilities*. Washington, D.C.: Environmental  
916 Protection Agency.
- 917 EPA (2014). *Water Health and Economic Analysis Tool Version 3.0, Consequence Analysis Tool for*  
918 *Water Utilities*. Washington, D.C.: Environmental Protection Agency.
- 919 FEMA (2012). *Hazus-MH 2.1 User Manual*. Washington, D.C.: Federal Emergency Management  
920 Agency.
- 921 FEMA (2013). *Mitigation Assessment Team Report Hurricane Sandy in New Jersey and New York*  
922 *Building Performance Observations, Recommendations, and Technical Guidance*. Washington,  
923 D.C.: Federal Emergency Management Agency.
- 924 Matsubashi, M., Fukatani, W., Yokota, T., Ozaki, M., & Horie, N. (2012). *The Damage of Sewage*  
925 *Treatment Systems Caused by the Great East Japan Earthquake. International Symposium on*  
926 *Engineering Lessons Learned from the 2011 Great East Japan Earthquake*, Tokyo, Japan.
- 927 Miyajima, M. (2012). *Damage to Water Supply System Induced by the 2011 Great East Japan*  
928 *Earthquake. International Symposium on Engineering Lessons Learned from the 2011 Great East*  
929 *Japan Earthquake*, Tokyo, Japan.
- 930 *Morley, Kevin (2013). Correct reference to be provided in next draft.*
- 931 NYCDEP (2013). *New York City Wastewater Resiliency Plan: Climate Risk Assessment and Adaptation*  
932 *Study*. October 2013. New York City Department of Environmental Protection.
- 933 NIST (1996). *The January 17, 1995 Hyogoken-Nanbu (Kobe) Earthquake: Performance of Structures,*  
934 *Lifelines, and Fire Protection Systems*. Gaithersburg, MD: National Institute of Standards and  
935 Technology.
- 936 O'Rourke, T. (2014). *Resilient Lifeline Systems*, ASCE TCLEE LeVal Lund Lecture, April 2, 2014,  
937 California Institute of Technology, Pasadena, CA.
- 938 OSSPAC (2013). *The Oregon Resilience Plan, Reducing Risk and Improving Recovery for the Next*  
939 *Cascadia Earthquake and Tsunami*. Salem, OR: Oregon Seismic Safety Policy Advisory  
940 Commission.
- 941 Sanders, D.A. (1997.) *Damage to Wastewater Treatment Facilities from Great Flood of 1993. Journal of*  
942 *Environmental Engineering*. January 1997. Vol. 123, Issue 1.
-

**DISASTER RESILIENCE FRAMEWORK**  
**75% Draft for San Diego CA Workshop**  
**11 February, 2015**  
**Water and Wastewater Systems, References**

---

- 943 SFPUC (2006). *General Seismic Requirements for Design of New Facilities and Upgrade of Existing*  
944 *Facilities*. San Francisco, CA: San Francisco Public Utilities Commission.
- 945 Schiff, A. (1997). *Northridge Earthquake: Lifeline Performance and Post-Earthquake Response*.  
946 Gaithersburg, MD: National Institute of Standards and Technology.
- 947 Tang, A., & Edwards, C. (2014). *Tohoku, Japan, Earthquake and Tsunami of March 11, 2011 Lifeline*  
948 *Performance*. Reston, VA: American Society of Civil Engineers.